


SAVIN.[®]

Digital Imaging System
9935D/9935DP/9945DP

Operating
Instructions

Copier Reference



Introduction

This manual contains detailed instructions on the operation and maintenance of this machine. To get maximum versatility from this machine all operators should carefully read and follow the instructions in this manual. Please keep this manual in a handy place near the machine.

Please read the Safety Information before using this machine. It contains important information related to **USER SAFETY** and **PREVENTING EQUIPMENT PROBLEMS**.

Notes:

Some illustrations may be slightly different from your machine.

Certain options may not be available in some countries. For details, please contact your local dealer.

Operator Safety:

This machine is considered a CDRH class I laser device, safe for office/EDP use. The machine contains two 5-milliwatt, 760 - 800 nanometer wavelength, GaAlAs laser diodes. Direct (or indirect reflected) eye contact with the laser beam might cause serious eye damage. Safety precautions and interlock mechanisms have been designed to prevent any possible laser beam exposure to the operator.

Laser Safety:

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical unit in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement or the optical subsystem is required.

Warning:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Notes:

The model names of the machines do not appear in the following pages. Check the type of your machine before reading this manual. (For details, see => P.1 "Machine Types".)

- Type 1: 9935D
- Type 2: 9935DP
- Type 3: 9945DP

Certain types might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the Inch version.

For good copy quality, Savin recommends that you use genuine Savin toner.

Savin shall not be responsible for any damage or expense that might result from the use of parts other than genuine Savin parts in your Savin office product.

Power Source:

120 V, 60 Hz, 10 A or more

Please be sure to connect the power cord to a power source as above. For details about power source, see => P.167 "Power Connection".

Read this manual carefully before you use this product and keep it handy for future reference.

For safety, please follow the instructions in this manual.

SAFETY INFORMATION

When using your machine, the following safety precautions should be always be followed.

Safety During Operation

In this manual, the following important symbols are used:

⚠ WARNING:

Ignoring this warning could cause serious injury or even death.

⚠ CAUTION:

Ignoring this caution could cause injury or damage to property.

Examples Of Indications



Symbols ⚠ mean a situation that requires you take care.



Symbols ⚠ mean "Hot surface".



Do NOT carry out the operation represented by this symbol ⚡.

This example means "Do not take apart".



Symbols ● mean you MUST perform this operation.

This example means "You must remove the wall plug".

WARNING:



- Only connect the machine to the power source described on the inside front cover of this manual.
- Avoid multi-wiring.
- Do not damage, break or make any modifications to the power cord. Do not place heavy objects on it, pull it hard or bend it more than necessary. These actions could cause an electric shock or fire.
- Do not plug or unplug the power cord with your hands wet. Otherwise, an electric shock might occur.



- Make sure the wall outlet is near the machine and freely accessible so that in event of an emergency it can be unplugged easily.



- Do not remove any covers or screws other than those specified in this manual. Some parts of the machine are at a high voltage and could give you an electric shock. Also, if the machine has laser systems, direct (or indirect) reflected eye contact with the laser beam may cause serious eye damage. When the machine needs to be checked, adjusted, or repaired, contact your service representative.
- Do not take apart or attempt any modifications to this machine. There is a risk of fire, electric shock, explosion or loss of sight. If the machine has laser systems, there is a risk of serious eye damage.



- If the machine looks damaged or breaks down, smoke is coming out, there is a strange smell or anything looks unusual, immediately turn off the operation and main power switches then unplug the power cord from the wall. Do not continue using the machine in this condition. Contact your service representative.
- If metal, liquid or foreign matter falls into the machine, turn off the operation and main power switches, and unplug the main power cord. Contact your service representative. Do not keep using the machine with a fault or defect.



- Do not put any metal objects or containers holding water (e.g. vases, flowerpots, glasses) on the machine. If the contents fall inside the machine, a fire or electric shock could occur.



- *Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of the used toner containers according to local regulations for plastics.*

CAUTION:



- Keep the machine away from humidity and dust. A fire or an electric shock might occur.
- Do not place the machine on an unstable or tilted surface. If it topples over, it could cause injury.



- After you move the machine, fix it with the caster fixture. Otherwise, the machine might move or come down to cause a personal injury.



- When you move the machine, unplug the power cord from the wall outlet to avoid fire or electric shock.
- When the machine will not be used for a long time, unplug the power cord.



- When you pull out the plug from the socket, grip the plug to avoid damaging the cord and causing fire or electric shock.



- If you use the machine in a confined space, make sure there is a continuous air turnover.



- Do not reuse stapled paper. Do not use aluminum foil, carbon-containing paper or other conductive paper. Otherwise, a fire might occur.



- When removing misfed paper, do not touch the fusing section because it could be very hot.



- This machine has been tested for safety using this supplier's parts and consumables. We recommend you only use these specified supplies.



- Do not eat or swallow toner.
- Keep toner (used or unused) and toner containers out of reach of children.



- This equipment is only to be installed by a qualified service personnel.



- *Deliver to collection point for waste products. Do not be disposed of via domestic refuse collection.*

ENERGY STAR



As an Energy Star Partner, we have determined that this machine model meets Energy Star Guidelines for energy efficiency.

This product was designed to reduce the environmental impact associated with copying equipment by means of energy saving feature such as Auto Off mode. For details, see the following pages.

❖ **Auto Off Timer**

See "10. Auto Off Timer" in "System Settings $^{3/6}$ " in the System Settings.

❖ **Low Pwr. Shift Time**

See "07. Low Pwr. Shift Time" in "System Settings $^{2/6}$ " in the System Settings.

❖ **Duplex Priority**

See "10. Duplex Priority" in => P.153 "1. General Features $^{3/4}$ ".

❖ **Recycled Paper**

Please contact your sales or service representative for recommended recycled paper types that may be used in this machine.

HOW TO READ THIS MANUAL

Symbols

In this manual, the following symbols are used:

 **WARNING:**

This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

 **CAUTION:**

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

* The statements above are notes for your safety.

 **Important**

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

 **Preparation**

This symbol indicates the prior knowledge or preparations required before operating.

 **Note**

This symbol indicates precautions for operation, or actions to take after misoperation.

 **Limitation**

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

 **Reference**

This symbol indicates a reference.


[]

Keys that appear on the machine's panel display.

[]

Keys built into the machine's operation panel.

WHAT YOU CAN DO WITH THIS MACHINE (COPY MODE)






TABLE OF CONTENTS

MACHINE TYPES	1
GUIDE TO COMPONENTS	2
Guide.....	5
OPTIONS	7
Type 1	7
Type 2 and Type 3	8
FUNCTION LIST BASED ON OPTIONS.....	9
OPERATION PANEL.....	12
PANEL DISPLAY.....	14
Displays And Key Operations	14
Display Panel Layout	16

1. BASICS

STARTING THE MACHINE	17
Turning On The Power.....	17
Turning Off The Power.....	18
CHANGING MODES.....	19
ORIGINALS.....	20
Sizes And Weights Of Recommended Originals.....	20
Sizes Difficult To Detect	21
Original Sizes And Scanning Area/Missing Image Area	22
COPY PAPER	23
Recommended Paper Sizes And Types	23
Non-recommended Paper	25
Paper Storage	26
TONER	27
Handling Toner.....	27
Toner Storage	27
Used Toner	27

2. COPYING

BASIC PROCEDURE	29
SETTING ORIGINALS	31
Setting Originals On The Exposure Glass	31
Setting Originals In The Document Feeder.....	32
Using SADF, Mixed Sized, and Thin Paper modes	33
BASIC FUNCTIONS	37
Adjusting Copy Image Density	37
Enhanced Image Copy.....	38
Selecting Original Type Setting.....	39

>Selecting Copy Paper	40
Auto Reduce/Enlarge—Having The Machine Choose The Reproduction Ratios	42
SORT/STACK/STAPLE	43
Sort—Sorting Into Sets (123, 123, 123)	45
Stack—Stacking Together All Copies Of A Page (111, 222, 333)	47
Staple	49
COPYING FROM THE BYPASS TRAY.....	55
When copying onto OHP transparencies or thick paper	58
PROGRAM—STORING YOUR COPY SETTINGS IN MEMORY	60
Storing Your Settings	60
Deleting A Program.....	61
Recalling A Program	62
OTHER FUNCTIONS	63
Energy Saver Mode—Saving Energy	63
Interrupt—Temporarily Stopping One Job To Copy Something Else.....	63
User Codes	63
Auto Start—Entering Copy Job Settings During The Warm-up Period.....	64
Original Beeper	64
PRESET REDUCE/ENLARGE—REDUCING AND ENLARGING USING PRESET RATIOS.....	65
ZOOM—REDUCING AND ENLARGING IN 1 % STEPS.....	67
DIRECTIONAL SIZE MAGNIFICATION (INCH)—STRETCHING AND SQUEEZING THE IMAGE INTO THE COPY AREA	69
DIRECTIONAL MAGNIFICATION (%)—STRETCHING AND SQUEEZING THE IMAGE IN 1 % STEPS.....	71
MARGIN ADJUSTMENT—ADJUSTING THE MARGIN	73
ERASE CENTER/BORDER—ERASING THE CENTER AND THE BORDER	75
COMBINE—COMBINING ORIGINALS INTO ONE COPY	78
SERIES COPIES—MAKING ONE-SIDED COPIES FROM VARIOUS ORIGINALS.....	82
Book → 1-Sided—Making One-sided Copies From Two Facing Page Of A Bound Original (Book)	82
2-Sided→1-Sided—Making One-sided Copies From Two-sided Originals	84
DUPLEX—MAKING TWO-SIDED COPIES.....	85
1-Sided → 2-Sided—Making Two-sided Copies From One-sided Originals	86
Book → 2-Sided—Making Two-Sided Copies From Facing Pages Of A Bound Original (Book)	89
2-Sided → 2-Sided—Making Two-sided Copies From Two-sided Originals	90
COVER/PAPER DESIGNATE—ADDING OR INSERTING SHEETS	91

Front Cover—Copying Or Adding A Front Cover.....	91
Both Covers—Copying Or Adding Front And Back Covers	93
Paper Designate—Copying Designated Pages Of Originals Onto Slip Sheets.....	94
OHP SLIP SHEET—COPYING OR INSERTING SLIP SHEET.....	96
POSITIVE/NEGATIVE—COPYING IN COMPLEMENTALY COLORS....	98
IMAGE REPEAT—REPEATING AN IMAGE.....	99
Double Copies—Copying The Image Twice On One Page	99
Image Repeat—Repeating An Image Over The Entire Copy	100
ARCHIVE FILE—STORING THE IMAGES OF YOUR ORIGINALS INTO MEMORY	102
Storing The Images.....	103
Deleting The Stored Images	105
Printing A List Of The Stored Images.....	106
Recalling The Stored Images.....	107
COMBINATION CHART	108
3. WHAT TO DO IF SOMETHING GOES WRONG	
IF YOUR MACHINE DOES NOT OPERATE AS YOU WANT	111
Message.....	111
Display	112
IF YOU CANNOT MAKE CLEAR COPIES.....	113
IF YOU CANNOT MAKE COPIES AS YOU WANT	115
Adjust Image	116
Combine.....	117
Duplex	118
LOADING PAPER.....	119
Loading Paper In The Large Capacity Tray	120
ADDING TONER.....	121
CLEARING MISFEEDS	124
CHANGING THE PAPER SIZE	132
ADDING STAPLES.....	134
1000-Sheet Finisher.....	134
3000-Sheet Finisher.....	136
REMOVING JAMMED STAPLES.....	139
1000-Sheet Finisher.....	139
3000-Sheet Finisher.....	141
REMOVING PUNCH WASTE	144
4. USER TOOLS (COPY FEATURES)	
ACCESSING THE USER TOOLS (COPY FEATURES).....	145
Exiting From User Tools.....	146

USER TOOLS MENU (COPY FEATURES).....	148
SETTINGS YOU CAN CHANGE WITH THE USER TOOLS.....	150
1. General Features $\frac{1}{4}$	150
1. General Features $\frac{2}{4}$	152
1. General Features $\frac{3}{4}$	153
1. General Features $\frac{4}{4}$	154
2. Adjust Image $\frac{1}{2}$	155
2. Adjust Image $\frac{2}{2}$	157
3. Input/Output $\frac{1}{2}$	160
3. Input/Output $\frac{2}{2}$	162
4. Shortcut Keys $\frac{1}{1}$	164

5. REMARKS

DO'S AND DON'TS.....	165
WHERE TO PUT YOUR MACHINE.....	166
Machine Environment	166
Power Connection.....	167
Access To Machine.....	168
MAINTAINING YOUR MACHINE	169
Cleaning The Exposure Glass	169
Cleaning The Platen Cover	169
Cleaning The Document Feeder.....	169

6. SPECIFICATION


MAINFRAME.....	171
DOCUMENT FEEDER (OPTION).....	176
PAPER TRAY UNIT (OPTION).....	177
INTERNAL TRAY 2 (1 BIN TRAY) (OPTION).....	178
1000-SHEET FINISHER (OPTION)	179
3000-SHEET FINISHER (OPTION)	180
PUNCH KIT (OPTION).....	182
LARGE CAPACITY TRAY (LCT) (OPTION)	183
DUPLEX UNIT (OPTION)	184
BYPASS TRAY (OPTION).....	185
8 MB COPIER MEMORY UNIT (ELECTRIC SORT KIT) (OPTION)	186
COPIER HARD DISK (IMAGE ENHANCE KIT).....	187
INDEX.....	188

MACHINE TYPES

There are three models of this machine. The main differences between them are memory capacity and copy speed. To make sure which model you have, see the inside front cover.

	Type 1	Type 2	Type 3
Copy speed	35 copies/minute (A4, 8 ¹ / ₂ " × 11")	35 copies/minute (A4, 8 ¹ / ₂ " × 11")	45 copies/minute (A4, 8 ¹ / ₂ " × 11")
Memory capacity	4 MB (8 MB optional memory available)	12 MB	12 MB
Fax unit	Option	Option	Option

GUIDE TO COMPONENTS



NDX4202E

1. Platen cover (option) or Document Feeder (ADF) (option)

Lower the platen cover over originals placed on the exposure glass for copying. If you have the document feeder, insert a stack of originals here. They will be fed automatically.

(The illustration shows the document feeder.)

2. Exposure glass

Position originals here face down for copying. See ⇒ P.20 "Originals".

3. Internal tray

Copied paper is delivered here face down.

4. Main power switch

Do not touch this switch. This switch is used only by a service representative when the optional fax unit is installed.

⌚ Note

If the machine does not operate after turning on the operation switch, check

if the main power switch is turned on. If it is off, turn it on.

5. ADF external tray

Originals are delivered here.

6. Main Power indicator

This indicator lights up when the main power switch is turned on, and goes off when the switch is turned off.

7. On indicator

This indicator lights up when the operation switch is turned on, and goes off when the switch is turned off.

8. Operation switch

Press this switch to turn the power on (the **On** indicator lights up). To turn the power off, press this switch again (the **On** indicator goes off).

9. Operation panel

See ⇒ P.12 "Operation Panel".

10. Duplex unit (Unit for two-sided copies) (option for Type 1)

Makes two-sided copies.


11. Front cover

Open to access the inside of the machine.

12. Paper tray

Set paper here. See ⇒ P.119 “ *Loading Paper*”.

13. Paper tray unit (option)



NDEA0101

1. Bypass tray (option for Type 1)


Use to copy onto OHP transparencies, adhesive labels, translucent paper, post cards, and non-standard size paper. See => P.55 "Copying From The Bypass Tray".

2. Right side cover

Open this cover before making 2-sided copies on B4, 8 1/2" x 14" or larger copy paper.

3. Lower right cover

Open this cover to remove jammed paper which fed from the optional paper tray unit.



NDEA0102

1. Ventilation hole

Prevents overheating. Do not obstruct the ventilation hole by placing or leaning


an object near it. If the machine overheats, a fault might occur.

Guide

The guides of the internal tray minimize curled copies when they are delivered. Raise these guides when you make copies on A3, 11" × 17" or thin paper.


❖ **To copy onto A3, 11" × 17" paper**

Raise the end fence.




NDGP0100

❖ **If either side of the OHP transparencies or thin paper is curled**



Raise the left end of the guide until it clicks.




NDGP0200


❖ If the end of the sheet is curled



① Remove the guide.




② Reinstall the guide in the opposite direction.



OPTIONS

Type 1



1. 1000-sheet finisher

Sorts, stacks, and staples copies.

2. External tray

If you selected this as the output tray, copied paper is delivered here face down. See "15. Output Tray" in the System Settings.

3. Platen cover

Lower this cover over originals for copying.

4. Document feeder (ADF)

Insert a stack of originals here. They will be fed automatically.

5. Internal tray 2 (1 bin tray)

If you selected this as the output tray, copied paper is delivered here face down. See "15. Output Tray" in the System Settings.

6. Bridge unit

Relays copies to the external tray or finisher. (The Punch function is optional.)

7. Paper tray unit

Consists of two paper trays.

8. Large Capacity Tray (LCT)

Holds 1,500 sheets of paper.

9. Bypass tray

Use to copy onto OHP transparencies, adhesive labels, translucent paper, post cards, and non-standard size paper. See ⇒ P.55 "Copying From The Bypass Tray".


10. Duplex unit

Use to make two-sided copies.

Other options:

- Interchange unit
- 8 MB copier memory unit (Electric sort kit)
- Copier hard disk (Image enhance kit)

Type 2 and Type 3



1. 1000-sheet finisher

Sorts, stacks, and staples copies.

2. External tray

If you selected this as the output tray, copied paper is delivered here face down. See "15. Output Tray" in the System Settings.

3. Platen cover

Lower this cover over originals for copying.

4. Document feeder (ADF)

Insert a stack of originals here.
They will be fed automatically.

5. Internal tray 2 (1 bin tray)

If you selected this as the output tray, copied paper is delivered here face down. See "15. Output Tray" in the System Settings.

6. 3000-sheet finisher (only for Type 3)

Sorts, stacks, staples copies, and makes punch holes (The Punch function is optional).

- 1: Proof tray
- 2: Shift tray

7. Bridge unit

Relays copies to the external tray or finisher.

8. Paper tray unit

Consists of two paper trays.

9. Large Capacity Tray (LCT)

Holds 1,500 sheets of paper.

Other options:

- Copier hard disk (Image enhance kit)
- Punch kit (only for Type 3 with 3000-sheet finisher)

FUNCTION LIST BASED ON OPTIONS

The function that are available to you depend on your machine configuration and which options you have. See the table below.

○...Available

✗...Not available

	Model				Place originals		
	Type 1	Type 1 with 8 MB copier memory unit	Type 1 with 8 MB copier memory unit and copier hard disk	Type 2, Type 3	Type 2, Type 3 with copier hard disk	on the exposure glass	in the document feeder
Adjusting Image Density	○	○	○	○	○	○	○
Selecting Original Type	○	○	○	○	○	○	○
Auto Paper Select	○	○	○	○	○	○	○
Selecting Copy Paper	○	○	○	○	○	○	○
Auto Reduce/Enlarge	○	○	○	○	○	○	○
Enhanced Image Copy	○	○	*1	○	*1	○	○
Sort	✗	○	○	○	○	○	○
Rotate Sort/Rotate Stack	✗	*2	*2	*2	*2	○	○
Shift Sort/Shift Stack	✗	*3	*3	*3	*3	○	○
Stapling	✗	*3	*3	*3	*3	○	○
Copying from the Bypass Tray	*4	*4	*4	○	○	○	○
Program	○	○	○	○	○	○	○
Reduce/Enlarge	○	○	○	○	○	○	○
Zoom	○	○	○	○	○	○	○
Directional Size Magnification (inch)	○	○	○	○	○	○	○
Directional Magnification (%)	○	○	○	○	○	○	○
Margin Adjustment	○	○	○	○	○	○	○
Erase Center/Border	○	○	○	○	○	○	○

		Model						Place originals
		Type 1	Type 1 with 8 MB copier memory unit	Type 1 with 8 MB copier memory unit and copier hard disk	Type 2, Type 3	Type 2, Type 3 with copier hard disk	on the exposure glass	in the document feeder
Combine	2 pages → 1-sided	○	○	○	○	○	○	○
	4 pages → 1-sided	○	○	○	○	○	○	○
	8 pages → 2-sided	×	*5	*5	○	○	○	○
	4 pages → 2-sided	×	*5	*5	○	○	○	○
	16 pages → booklet	×	*5	*5	○	○	○	○
Series Cop- ies	Book → 1-sided	○	○	○	○	○	○	○
	2-sided → 1-sided	*6	*6	*6	*6	*6	×	○
Duplex	1-sided → 2-sided	×	*5	*5	○	○	○	○
	Book → 2-sided	×	*5	*5	○	○	○	○
	2-sided → 2-sided	×	*5	*5	○	○	○	○
Cover/Paper Designate		*4 *7	*4	*4	○	○	○	○
OHP Slip Sheet		*4	*4	*4	○	○	○	○
Positive/Negative		○	○	○	○	○	○	○
Repeat	Double copies	○	○	○	○	○	○	○
	Image Repeat	○	○	○	○	○	○	○
Archive File		×	×	○	×	○	○	×

*1 Standard setting.

*2 Set the paper of the same size in the paper trays.

*3 Finisher required.


*4 Bypass tray required.

*5 Duplex unit and interchange unit required.

*6 Document Feeder required.

*7 Only a set of copies can be made.

OPERATION PANEL



1. Operation panel for facsimile mode (for machine with optional fax function)

See the "Facsimile Reference".

2. [Sorter] key

Sort/Rotate Sort/Shift Sort: automatically sorts copies.

Rotate Stack/Shift Stack: stacks together copies of each page.

Staple: staples each set of copies together.

3. [Duplex] key

Makes two-sided copies. See \Rightarrow P.85 "Duplex—Making Two-Sided Copies".

4. [User Tools/Counter] key

- User Tools

Press to change the default settings and conditions to meet your requirements.

- Counter

Press to check or print the total number of copies made.

See \Rightarrow P.145 "USER TOOLS (COPY FEATURES)".

5. Indicators

These indicators show errors or the status of the machine.

See \Rightarrow P.111 "WHAT TO DO IF SOMETHING GOES WRONG".

6. Panel display

Shows operation status, error messages, and function menus. See \Rightarrow P.14 "Panel Display".

7. [Program] key

Press to select the program mode. See \Rightarrow P.60 "Program—Storing Your Copy Settings In Memory".

8. [Clear Modes/Energy Saver] key

Press to clear the previously entered copy job settings. Also use to switch to and from Energy Saver mode. See \Rightarrow P.63 "Energy Saver Mode—Saving Energy".

9. [Interrupt] key


Press to make interrupt copies during a copy run. See \Rightarrow P.63 "Interrupt—Temporarily Stopping One Job To Copy Something Else".

10. Main Power indicator

This indicator lights up when the main power switch is turned on, and goes off when the switch is turned off.

11. On indicator

This indicator lights up when the operation switch is turned on, and goes off when the switch is turned off.



12. Operation switch

Press this switch to turn the power on (the **on** indicator lights up). To turn the power off, press this switch again (the **on** indicator goes off).

13. [Enhanced Image] key

Reproduces copies with a better image quality.

14. [Menu] key

Displays the names of available functions.

15. Shortcut keys

Press to use the stored functions you frequently use.

16. [Zoom] key

Changes the reproduction ratio in 1 % steps.

17. [Auto Reduce/Enlarge] key

Enlarges or reduces the image automatically according to the specified paper size.

18. Function keys

Press to change modes. To use copy functions, press the **[Copy]** key.

19. [Original Type] key

Press to select the type of your originals.

20. [Lighter] and [Darker] keys and [Auto Image Density] key

Adjusts the copy image density.

21. Selection keys

Press the key under the item you wish to select.

22. $\leftarrow\rightarrow$ keys (Cursor keys)

Press to select an item on the panel display.

23. Operation panel for facsimile mode (for machines with optional fax function)

See the "Facsimile Reference".

24. [Number] keys

Use to enter the desired number of copies and data for selected modes.

Use the **[#]** key to enter data in selected modes.

25. [Start] key

Press to start copying. Use to set the Auto Start. See \Rightarrow P.64 "Auto Start—Entering Copy Job Settings During The Warm-up Period".

26. [Clear/Stop] key

While entering numbers, press to cancel a number to have entered. While copying, press to stop copying.

PANEL DISPLAY

The panel display shows operational status, error messages, and function menus.

Important

- Do not apply a strong shock or force of about 30 N (about 3 kgf) or more to the panel display. Otherwise, the display might be damaged.

Note


- When you select or specify an item on the panel display, it is highlighted like **Auto**.
- Keys appearing as  cannot be used.
- By default, the machine is in Copy mode when you switch on. This can be changed. See "Settings You Can Change With The User Tools" of the System Settings.

Displays And Key Operations

Note


- The following illustrations are examples for the machine with the optional paper tray unit and large capacity tray installed.

❖ Copy initial display



1. The function items for the selected function are displayed.
2. Number of originals set.
3. Displays operational status or messages.
4. These keys correspond to the item on the display.
Press a relevant key to select a function.
 - To move the selection to the left, press the  key.
 - To move the selection to the right, press the  key.
5. Displays items which can be selected or specified.

❖ Function menu display



1. When you select a function name, ✓ mark appears before the name.
2. Displays operational status or message.
3. Displays items which can be selected or specified.


❖ Common keys

[OK]	Sets a selected function or entered value and returns to the previous display.
[Cancel]	Cancels a selected function or entered value and returns to the previous display.
[↑Prev.][↓Next]	When there are too many items fit on the display, use these keys to move between pages.
[OK]	Press to highlight the selection you wish to select.
[Menu]	Press to return to the previous menu.
[Exit]	Sets a selected function or entered value and returns to the initial display.

Display Panel Layout


The basic elements used on the display are shown below. Understanding their meaning helps you exploit this machine's features quickly and easily.

❖ Sample Display for Erasing the Center/Border



1. Operational status or message.
2. Selectable/specifiable functions are displayed.
3. Screened key means to press it.

↓ Press the [Center] key.



1. Selectable/specifiable functions are displayed.
2. Cancels the settings and returns to the previous display.
3. Confirms the settings and returns to the previous display.

1. BASICS

STARTING THE MACHINE

To start the machine, turn on the operation switch.

Note

- This machine automatically enters Energy Saver mode or turns itself off if you do not use the machine for a while. See "09. Energy Saver Mode", "10. Auto Off Timer" of the System Settings.

Power switches

This machine has two power switches: See ⇒ P.2 "Guide To Components".

❖ Operation switch (right side of the operation panel)

Turn on this switch to activate the machine. When the machine has warmed up, you can make copies or send faxes.

❖ Main power switch (left side of the machine)


Do not touch the main power switch. It should be used only by a service representative when the optional fax unit is installed.

Important


- If you leave the main power switch off for more than about one hour, all fax files in memory will be lost. See "Turning Off The Power" of the Facsimile Reference.

Turning On The Power

- 1 Make sure that the power cord is plugged into the wall outlet firmly and the **Main Power** indicator is lit.
- 2 Press the operation switch to make the **On** indicator light up.



The panel display will come on.



Note

- During the warm-up period, you can use the Auto Start function. See ⇒ P.64 "Auto Start—Entering Copy Job Settings During The Warm-up Period".
- Warm-up period is as follows:
 - Type 1 and Type 2: less than 85 seconds
 - Type 3: less than 100 seconds

When the machine is set for user codes

1 Enter your user code using the [Number] keys. Then press the [#] key.

Note

- To prevent others from making copies with your user code, press the [Clear Modes/Energy Saver] key and the [Clear/Stop] key simultaneously after copying.

Reference

For setting user codes, see ⇒ P.154 "1. General Features 4/4".

When the [Clear Modes/Energy Saver] indicator is lit

The machine is in Energy Saver mode.

1 Press the [Clear Modes/Energy Saver] key.

The machine will return to the ready condition.

Note


- The machine will also return to the ready condition when an original is set in the document feeder, or when the platen cover or document feeder is opened.

Reference

See "08. Low Power Timer" of the System Settings.

Turning Off The Power


1 Press the operation switch to make the On indicator go off.

**Important**

- If you want to unplug the power cord or turn off the main power switch, make sure that the remaining memory space indicates 100 % on the display for facsimile mode.
- Fax files stored in memory will be lost an hour after you turn the main power switch off or you unplug the power cord. See "Turning Off The Power" of the Facsimile Reference.

CHANGING MODES

You can use this machine not only as a copier, but optionally as a fax machine as well. Press the **[Copy]** key to use functions, or press the **[Fax]** key to use facsimile functions.



ND6X02EE

Limitation

□ You cannot switch modes in any of the following cases:

- When scanning in a fax message for transmission.
- During immediate transmission.
- When accessing the user tools.
- During interrupt copying.

ORIGINALS



Sizes And Weights Of Recommended Originals

❖ Metric version

Where original is set	Original Size	Original Weight
Exposure glass	Up to A3	--
Document feeder	1-sided originals: A3□ – B6□□	52 – 128 g/m ²
	2-sided originals: A3□ – A5□□	52 – 105 g/m ²
	Thin Paper mode: A3□ – A5□□	41 – 128 g/m ²

❖ Inch versions

Where original is set	Original Size	Original Weight
Exposure glass	Up to 11" × 17"	--
Document feeder	1-sided originals: 11" × 17"□ – 5 1/2" × 8 1/2"□□	14 – 34 lb
	2-sided originals: 11" × 17"□ – 5 1/2" × 8 1/2"□□	14 – 28 lb
	Thin Paper mode: 11" × 17"□ – 5 1/2" × 8 1/2"□□	11 – 34 lb

Non-recommended originals for the document feeder

Setting the following originals in the document feeder might cause paper misfeeds or damage to the originals. Set these originals on the exposure glass.

- Originals other than those specified in ⇒ P.20 “Sizes And Weights Of Recommended Originals”
- Stapled or clipped originals
- Perforated or torn originals
- Curled, folded, or creased originals
- Pasted originals
- Originals with any kind of coating, such as thermal fax paper, art paper, aluminum foil, carbon paper, or conductive paper
- Originals with indexes, tags, or other projecting parts
- Sticky originals such as translucent paper
- Thin original that has low stiffness

- Originals of inappropriate weight ⇒ P.20 “*Sizes And Weights Of Recommended Originals*”
- Bound originals such as books
- Transparent originals such as OHP transparencies or translucent paper

1

Sizes Difficult To Detect

It is difficult for the machine to detect the sizes of the following originals, so select the paper size manually.

- Originals with indexes, tags, or other projecting parts
- Transparent originals such as OHP transparencies or translucent paper
- Dark originals with many letters and drawings
- Originals which partially contain solid image
- Originals which have solid image at their edges
- Originals other than those (with ○) in the table below. See ⇒ P.21 “*Sizes detectable by the Auto Paper Select*”.

Sizes detectable by the Auto Paper Select

❖ Metric version

Size Place of original	A3 □	B4 □	A4 □□	B5 □□	A5 □□	11" × 17"□	8 $\frac{1}{2}$ " × 14"□	8 $\frac{1}{2}$ " × 11"□	5 $\frac{1}{2}$ " × 8 $\frac{1}{2}$ "□	8 $\frac{1}{2}$ " × 13"□ *1
Exposure glass	○	○	○	○	×	×	×	×	×	○
Docu- ment feeder	○	○	○	○	○	○	×	○	..	○

*1 You can select from 8 $\frac{1}{2}$ " × 13", 8 $\frac{1}{4}$ " × 13" and 8" × 13" using the user tool (system settings). See “24. <F/F4> Size Setting” in the System Settings.


❖ Inch version

Size Place of original	A3 □	B4 □	A4 □□	B5 □□	A5 □□	11" × 17"□	8 $\frac{1}{2}$ " × 14"□	8 $\frac{1}{2}$ " × 11"□	5 $\frac{1}{2}$ " × 8 $\frac{1}{2}$ "□	8 $\frac{1}{2}$ " × 13"□ *1
Exposure glass	×	×	×	×	×	○	○	○	×	×
Docu- ment feeder	×	×	○	×	×	○	○	○	○	○


*1 You can select from 8 $\frac{1}{2}$ " × 13", 8 $\frac{1}{4}$ " × 13" and 8" × 13" using the user tool (system settings). See “24. <F/F4> Size Setting” in the System Settings.

Original Sizes And Scanning Area/Missing Image Area

❖ Exposure glass



❖ Document feeder



● Limitation

- Even if you correctly set originals in the document feeder or on the exposure glass, 3 mm margins on all four sides might not be copied.

COPY PAPER

Recommended Paper Sizes And Types

The following limitations apply to each tray:

		Metric version	Inch version	Paper weight	Paper capacity
Paper tray		A3□, B4□, A4□, B5□, A5□, 11"×17"□, 8 ¹ / ₂ "×14"□, 8 ¹ / ₂ "×11"□, 5 ¹ / ₂ "×8 ¹ / ₂ "□, 7 ¹ / ₄ "×10 ¹ / ₂ "□, 8"×13"□, 8 ¹ / ₂ "×13"□, 8 ¹ / ₄ "×13"□		64–105 g/m ² , 20–28 lb	500 sheets
Paper tray unit (option)		Note	<input type="checkbox"/> You have to specify paper size using the user tools. See ⇒ P.132 "Changing The Paper Size".		
Bypass tray	Standard size	A3□, A4□, A5□, 8 ¹ / ₂ "×13"□	A3□, 11"×17"□, 8 ¹ / ₂ "×14"□, 8 ¹ / ₂ "×11"□, 5 ¹ / ₂ "×8 ¹ / ₂ "□	52–157 g/m ² , 16–42 lb	50 sheets (52–90 g/m ² , 16–20 lb), 25 sheets (91–157 g/m ² , 20–42 lb)
	Non-standard size ^{*1}	Vertical: 100–297 mm Horizontal: 148–432 mm	Vertical: 4.0"–11.7" Horizontal: 6.0"–17.0"	52–157 g/m ² , 16–42 lb	1 sheet
Postcards, adhesive labels, translucent paper					
Large capacity tray (option)	A4□	8 ¹ / ₂ "×11"□		64–105 g/m ² , 20–28 lb	1,500 sheets

^{*1} When you set non-standard size paper in the bypass tray, you have to specify the size. See ⇒ P.55 "Copying From The Bypass Tray".

Important

- If you use damp or curled paper, a misfeed might occur. In such a case, try turning over the paper stack in the paper tray. If there is no improvement, change to copy paper with less curl.

 **Note**

When you use the bypass tray, it is recommended to set the copy paper direction to .



Post cards should be fed from the bypass tray.

If you load paper of the same size and in the same direction in two or more trays, the machine automatically shifts to another tray when the tray in use runs out of paper. This function is called Auto Tray Switch. (If you put recycled paper or special paper in paper trays using the Special Paper Indicate menu, this function is not available to these trays unless their settings are identical.) This saves interrupting a copy run to replenish paper even when you make a large number of copies. You can cancel this setting. See "13. Auto Tray Switch" and "14. Sp. Paper Ind." of the System Settings.

 **Reference**

If you want to add paper, see ⇒ P.119 " *Loading Paper*".

If you want to change the paper size, see ⇒ P.132 "*Changing The Paper Size*".

Non-recommended Paper

CAUTION:



- Do not reuse stapled paper. Do not use aluminum foil, carbon-containing paper or other conductive paper. Otherwise, a fire might occur.

Important

Do not use paper with any kind of coating such as:

- Thermal fax paper
- Art paper
- Aluminum foil
- Carbon paper
- Conductive paper

Otherwise, a fault might occur.

Do not use copy paper that has been already copied on. Otherwise, a fault might occur.

Note

Do not use the following type of paper because a paper misfeed might occur.

- Bent, folded, or creased paper
- Torn paper
- Slippery paper
- Perforated paper
- Rough paper
- Thin paper that has low stiffness
- Paper with much paper dust on its surface

If you make a copy on rough grain paper, the copy image might be blurred.

Do not use paper which has been copied or printed on.

Paper Storage

Note

- When storing paper, the following precautions should always be followed:
 - Do not store paper where it will be exposed to direct sunlight.
 - Avoid storing paper in humid areas (humidity: 70 % or less).
 - Store on a flat surface.
- Keep open reams of papers in the package, and store as you would unopened paper.
- Under high temperature and high humidity, or low temperature and low humidity conditions, store papers in a vinyl bag.

TONER

Handling Toner

⚠ WARNING:



- *Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of the used toner containers according to local regulations for plastics.*

⚠ CAUTION:



- *Do not eat or swallow toner.*
- *Keep toner (used or unused) and toner containers out of reach of children.*

⚠ CAUTION:



- *This machine has been tested for safety using this supplier's parts and consumables. We recommend you only use these specified supplies.*

Important

If you use toner other than that recommended, a fault might occur.

Reference

If you want to add toner, see ⇒ P.121 “ Adding Toner”.

Toner Storage

Note

When storing toner, the following precautions should always be followed:

- Store toner containers in a cool, dry place free from direct sunlight.
- Do not store toner where it will be exposed to heat.
- Do not eat or swallow toner, and keep it out of reach of children.
- Store on a flat surface.

Used Toner

Note

Used toner cannot be re-used.



2. COPYING

BASIC PROCEDURE

1 Note


- As default, Type 1 with the duplex unit, Type 2, and Type 3 are initially in Duplex mode (1-sided → 2-sided). You can cancel Duplex mode by pressing the [Duplex] key. You can also change the default value. See "10. Duplex Priority" in ⇒ P.153 "1. General Features 3/4".

2 When the machine is set for user code, enter the user code with the [Number] keys and then press the [#] key.

Reference

See ⇒ P.63 "User Codes".

3 Make sure that the machine is in Copy mode.



4 Note

- If not, press the [Copy] key.

5 Make sure that there are no previous settings remaining.

6 Note

- To clear settings, press the [Clear Modes/Energy Saver] key.


7 Set your originals.

Reference

See ⇒ P.31 "Setting Originals".

8 Set your desired settings.

9 Enter the number of copies required with the [Number] keys.



10 Note

- The maximum copy quantity can be set between 1 and 999 (default: 999). See "05. Max. Copy Q'ty" in ⇒ P.152 "1. General Features 2/4".

- To change the number entered, press the [Clear/Stop] key and enter the new number.

11 Press the [Start] key.

The machine starts copying.

12 Note

- To stop the machine during the multi-copy run, press the [Clear/Stop] key.
- To return the machine to the initial condition after copying, press the [Clear Modes/Energy Saver] key.

2

Auto Reset

The machine returns to its initial condition automatically after your job is finished, after a certain period of time. This function is called "Auto Reset".

Note

- You can change the Auto Reset time. See "11. Auto Reset" in ⇒ P.153 "1. General Features 3/4".

Auto Off

The machine turns itself off automatically after your job is finished, after a certain period of time. This function is called "Auto Off".

Note

- You can change the Auto Off time. See "10. Auto Off Timer" in the System Settings.
- You can change the default settings for basic functions. See ⇒ P.150 "Settings You Can Change With The User Tools" and "USER TOOLS (SYSTEM SETTINGS)" in the System Settings.


SETTING ORIGINALS

● Limitation

- Set the original after correction fluid and ink has completely dried. Not taking this precaution could mark the exposure glass and cause marks to be copied.

● Note

- Basically the originals should be aligned to the rear left corner. However, some copy functions may produce different results depending on the direction of the originals. For details, see explanations of each function.



● Reference

See ⇒ P.20 "Originals".


Setting Originals On The Exposure Glass

1 Lift the platen cover or the document feeder.

● Note

- Be sure to open the platen cover or the document feeder by more than 30°, otherwise the original size might not be detected correctly.

2 Set the original face down on the exposure glass. The original should be aligned to the rear left corner.



1: Reference mark

2: Scale


3 Lower the platen cover or the document feeder.

Setting Originals In The Document Feeder

Note

- Do not stack originals above the limit mark.
- When copying thin originals (41 – 52 g/m², 11 – 14 lb), select [DF Setting] and set to Thin Paper mode, or set your originals on the exposure glass to avoid damage due to a multi-sheet feed (if several sheets are fed together at the same time). See ⇒ P.35 "Thin paper mode".
- The original might become dirty if it is written with a pencil or similar tools.
- For 1-sided originals, you can select the ADF tray or the ADF external tray as an output tray. See "22. ADF Orig. Ejection" in the System Settings.

2



1: ADF tray

2: ADF external tray


- Copying or scanning speed might be a little reduced if the ADF tray is selected as an output tray.

Reference

Regarding originals that the document feeder can handle, see ⇒ P.20 "Originals".

Setting a stack of originals in the document feeder

- 1 Adjust the guide to the original size.
- 2 Set the aligned originals face up into the document feeder.



1: Limit mark

2: Document guide

Note

- To avoid a multi-sheet feed, shuffle the originals before setting them in the document feeder.


When SADF mode is selected

Reference

See ⇒ P.33 "SADF mode".

- 1 Set one original face up into the document feeder. Then, press the [Start] key.
The Auto Feed indicator is lit.
- 2 Set the next original while the Auto Feed indicator is lit.

The second and subsequent originals can be fed automatically without pressing the [Start] key.



Note

- You can adjust the time the machine waits before being ready for the next original. See "SADF Auto Reset" in => P.160 "3. Input/Output 1/2".

Using SADF, Mixed Sized, and Thin Paper modes

SADF mode


If you set one original at a time in the document feeder, the second and subsequent originals can be fed automatically without pressing the [Start] key.

2


Limitation

- Copying or scanning speed might be a little reduced.


 Press the [Menu] key.



 Press the [↓Next] key until [DF Setting] is displayed.




3 Select [DF Setting] with the keys, then press the [Select] key.



2


4 Press the [Select] key.



Note

To deselect [SADF], press the [Select] key again.

5 Press the [Exit] key.



Mixed sizes mode


● **Limitation**

- The weight of originals that can be set with this function is 52 – 81 g/m², 14 – 20 lb.
- The paper sizes that can be set with this function are as follows:

Metric version	B5 – A3
Inch version	5 ¹ / ₂ " x 8 ¹ / ₂ " – 11" x 17"


- You can set originals of two different sizes at a time.
- Copying speed and scanning speed will be reduced.
- For smaller originals, the copy image might be slanted since the originals might not be correctly aligned with the original guide.

1 Press the [Menu] key.





ND20G03

2 Press the [Next] key until [DF Setting] is displayed.




ND20G0102

3 Select [DF Setting] with the keys, then press the [Select] key.



4 Select [Mixed Sizes] with the keys, then press the [Select] key.



1: Set into the document feeder (ADF).

2

Important

□ If the originals are of different vertical sizes, put the longer original on the bottom; otherwise the original size might not be detected correctly.

7 Adjust the guide to the widest original size.



8 Set the aligned originals face up into the document feeder.

Thin paper mode

Note

□ To deselect [Mixed Sizes], press the [Select] key again.

5 Press the [Exit] key.




6 Align the rear and left edges of the originals as shown in the illustration.


Note

□ Set to Thin Paper mode when you place thin paper into the document feeder; otherwise your originals may be damaged.

1 Press the [Menu] key.



2 Press the [**↓Next**] key until [DF Setting] is displayed.




2




N02C0102

3 Select [DF Setting] with the keys, then press the [Select] key.



N02C0109

4 Select [Thin Paper] with the keys, then press the [Select] key.




N02C0109

Note

□ To deselect [Thin Paper], press the [Select] key again.

5 Press the [Exit] key.



N02C0103

BASIC FUNCTIONS

The following basic functions are explained in this section.

❖ Adjusting Copy Image Density

Auto and Manual Image Density

❖ Enhanced Image Copy

This function provides clearer copy image.

❖ Selecting Original Type Setting

Text, Text-Photo, Photo, Copied original, Low density original

❖ Selecting Copy Paper

Auto Paper Select and Manual Paper Select

❖ Auto Reduce/Enlarge

The machine can choose an appropriate reproduction ratio based on the paper and original sizes you select.

>Note

- You can select functions to be activated when Auto Reset is turned on, when Energy Saver is turned off, or after the machine is powered on. See ⇒ P.150 "1. General Features ^{1/4}".
- You can change default settings for basic functions. See ⇒ P.150 "Settings You Can Change With The User Tools".

Adjusting Copy Image Density

You can adjust the copy image density to match your originals.

There are three types in this function:

2

❖ Auto Image Density

The machine automatically adjusts the image density.

❖ Manual Image Density

If you require darker or lighter copies, adjust the image density yourself.

❖ Combined Auto and Manual Image Density

Use when copying originals with a dirty background (such as newspapers). You can adjust the foreground density while leaving the background unchanged.

Reference

You can change the density level with the user tools. See "12. Density Pattern" in ⇒ P.153 "1. General Features ^{3/4}".

1 Select one of Image Density modes.

Auto Image Density

1 Make sure that the Auto Image Density indicator is lit.




Note

- If not, press the [Auto Image Density] key.


Manual Image Density

- ① Press the [Auto Image Density] key to cancel it.
- ② Press the [Lighter] or [Darker] key to adjust the image density.

2

**Combined Auto and Manual Image Density**

- ① Make sure that the Auto Image Density indicator is lit.
- ② Press the [Lighter] or [Darker] key to adjust the density.

**Enhanced Image Copy**

This function reproduces copies of better image quality. It is useful when copying detailed originals such as maps.

This function is turned on automatically if you have the optional copier hard disk.

Limitation

The optional copier hard disk is required to use this image enhanced feature with the following functions:


- Rotate Copy
- Sort/Stack/Staple
- Combine Copy
- Double Copy
- Sort involving cover/slip sheets
- Double Copy
- Repeat Copy

Note

Copying speed decreases from the normal speed as follows. However, the copying speed remains unchanged with the optional copier hard disk.

Type 1, Type 2	35 → 30 copies/min
Type 3	45 → 40 copies/min
for A4 □, 8 1/2" × 11" □	

1 Press the [Enhanced Image] key.



Selecting Original Type Setting

Select one of the following types to match your originals:

❖ **Text**

Select this mode when your originals contain only letters (no pictures).

❖ **Text-Photo**

Select Text-Photo when your originals contain photographs or pictures with letters.

❖ **Photo**

Delicate tones of photographs and pictures can be reproduced with this mode.

❖ **Special original (Copied original)**

If your originals are copies (generation copies), the copy image can be reproduced sharply and clearly. To use this mode, activate the Enhanced Image Copy function first.


❖ **Special original (Low density original)**

Select this mode for originals that have lighter lines written in pencil, or for faint copied slips. The faint lines will be clearly copied.

To use this mode, activate the Enhanced Image Copy function first.

If you do not select any mode, your originals will be scanned with the settings suitable for text originals (Text mode).

1 Press the [Original Type] key and select the original type.



2

Note


□ Press the [Original Type] key to step through the following types:

No indicator lit	Text
Top indicator lit	Text-Photo
Center indicator lit	Photo
Bottom indicator lit	Special Original

□ To use Special Original mode, press the [Enhanced Image] key first.

Special Original

① Select [Copied Orig.] or [Low Dens. Orig.] with the   keys, then press the [OK] key.

**Selecting Copy Paper**

There are two ways to select copy paper:

Auto Paper Select

The machine selects a suitable size of copy paper automatically based on the original size and the reproduction ratio.

Note

□ When the original is set at a different direction from the copy paper in the paper tray with Auto Tray Switch mode ON, the machine automatically rotates the original image by 90° to match the copy paper direction. This applies to the following paper sizes:

Metric version	A4   B5  
Inch version	8 1/2" x 11"  

Reference

For Auto Tray Switch, see "13. Auto Tray Switch" in the System Settings.

Manual Paper Select

You can select the desired copy paper size manually. You can also select the bypass tray.

Reference

See ⇒ P.55 "Copying From The Bypass Tray".

Note

□ When you use Auto Paper Select, refer to the following table for possible copy paper sizes and directions. (if the ratio is 100 %)

❖ Metric version

Where original is set	Paper size and direction
Exposure glass	A3 <input checked="" type="checkbox"/> , B4 <input checked="" type="checkbox"/> , A4 <input checked="" type="checkbox"/> , B5 <input checked="" type="checkbox"/> , 8½" × 13" <input checked="" type="checkbox"/> *1
Document feeder	A3 <input checked="" type="checkbox"/> , B4 <input checked="" type="checkbox"/> , A4 <input checked="" type="checkbox"/> , B5 <input checked="" type="checkbox"/> , A5 <input checked="" type="checkbox"/> , 11" × 17" <input checked="" type="checkbox"/> , 8½" × 11" <input checked="" type="checkbox"/> , 8½" × 13" <input checked="" type="checkbox"/> *1

*1 You can select from 8½" × 13", 8¼" × 13" and 8" × 13" using the user tool (system settings). See "24. <F/F4> Size Setting" in the System Settings.

❖ Inch version

Where original is set	Paper size and direction
Exposure glass	11" × 17" <input checked="" type="checkbox"/> , 8½" × 14" <input checked="" type="checkbox"/> , 8½" × 11" <input checked="" type="checkbox"/>
Document feeder	A4 <input checked="" type="checkbox"/> , 11" × 17" <input checked="" type="checkbox"/> , 8½" × 14" <input checked="" type="checkbox"/> , 8½" × 11" <input checked="" type="checkbox"/> , 5½" × 8½" × 8½" <input checked="" type="checkbox"/> , 8½" × 13" <input checked="" type="checkbox"/> *1


*1 You can select from 8½" × 13", 8¼" × 13" and 8" × 13" using the user tool (system settings). See "24. <F/F4> Size Setting" in the System Settings.

- For some originals, the original size might not be detected correctly. See ⇒ P.21 "Sizes Difficult To Detect".
- When you set special paper, such as recycled paper, in the paper tray, you can have the kind of paper shown on the display. See "14. Sp. Paper Ind." of the System Settings.

1 Select the copy paper.

Auto Paper Select


1 Make sure that the Auto (Auto Paper Select) is selected.



2

Manual Paper Select


1 Select the paper tray or bypass tray by pressing the [Paper] or keys.



Auto Reduce/Enlarge—Having The Machine Choose The Reproduction Ratios

2

The machine can choose an appropriate reproduction ratio based on the paper and original sizes you select.



◆ Note

When you use Auto Reduce/Enlarge, refer to the following table for possible original sizes and directions:

◆ Metric version

Where original is set	Original size and direction
Exposure glass	A3 <input type="checkbox"/> , B4 <input type="checkbox"/> , A4 <input type="checkbox"/> , B5 <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 13" <input type="checkbox"/> *1
Document feeder	A3 <input type="checkbox"/> , B4 <input type="checkbox"/> , A4 <input type="checkbox"/> , B5 <input type="checkbox"/> , A5 <input type="checkbox"/> , 11" \times 17" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 11" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 13" <input type="checkbox"/> *1

*1 You can select from 8 $\frac{1}{2}$ " \times 13", 8 $\frac{1}{4}$ " \times 13" and 8" \times 13" using the user tool (System Settings). See "24. <F/F4>Size Setting" in the System Settings.

◆ Inch version

Where original is set	Original size and direction
Exposure glass	11" \times 17" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 14" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 11" <input type="checkbox"/>

Where original is set	Original size and direction
Document feeder	A4 <input type="checkbox"/> , 11" \times 17" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 14" <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 11" <input type="checkbox"/> , 5 $\frac{1}{2}$ " \times 8 $\frac{1}{2}$ " <input type="checkbox"/> , 8 $\frac{1}{2}$ " \times 13" <input type="checkbox"/> *1

*1 You can select from 8 $\frac{1}{2}$ " \times 13", 8 $\frac{1}{4}$ " \times 13" and 8" \times 13" using the user tool (System Settings). See "24. <F/F4>Size Setting" in the System Settings.


The reproduction ratios the machine will select are as follows:

- Type 1, Type 2
Metric version: 25 – 400 %
Inch version: 25 – 400 %
- Type 3
Metric version: 35 – 400 %
Inch version: 32 – 400 %


For some originals, the original size might not be detected correctly. See \Rightarrow P.21 "Sizes Difficult To Detect".

You can set originals of different sizes in the document feeder at a time. See \Rightarrow P.34 "Mixed sizes mode".

1 Press the [Auto Reduce/Enlarge] key.



2 Select the paper tray by pressing the [Paper] or .



SORT/STACK/STAPLE

Type 1 requires the optional 8 MB copier memory unit to use these functions.

The machine can scan your originals into memory and automatically sort the copies.

❖ Sort

- Sort
- Rotate Sort
- Shift Sort
(the optional finisher required)

❖ Stack

- Rotate Stack
- Shift Stack
(the optional finisher required)

❖ Staple (the optional 1000-sheet finisher required)

- Top 2



❖ Staple (the optional 3000-sheet finisher required)

- Top 1



- Top 2



- Top 3



- Double



❖ Punch (the optional 3000-sheet finisher and punch kit required)

- Makes punch holes in combination with Sort/Stack/Staple.

2

❖ Limitation

- The optional 3000-sheet finisher and punch kit are for Type 3 only.
- You cannot use the bypass tray with this function.

❖ Note

- The maximum tray capacity is as follows. When the number of copies exceeds the tray capacity, remove copies from the tray.

❖ Metric version

Internal tray 1	<ul style="list-style-type: none"> • B4 or larger: 250 sheets (80 g/m²) • A4 or smaller: 500 sheets (80 g/m²)
Internal tray 2	125 sheets (80 g/m ²)
External tray	125 sheets (80 g/m ²)
1000-sheet finisher	<ul style="list-style-type: none"> • B4 or larger: 500 sheets (80 g/m²) • A4 or smaller: 1,000 sheets (80 g/m²)
3000-sheet finisher (without punch)	<ul style="list-style-type: none"> • Except A4: 1,500 sheets (80 g/m²) • A4: 3,000 sheets (80 g/m²)

2

❖ Inch version

Internal tray 1	<ul style="list-style-type: none"> • $8\frac{1}{2}'' \times 14''$ or larger: 250 sheets (20 lb) • $8\frac{1}{2}'' \times 11''$ or smaller: 500 sheets (20 lb)
Internal tray 2	125 sheets (20 lb)
External tray	125 sheets (20 lb)
1000-sheet finisher	<ul style="list-style-type: none"> • $8\frac{1}{2}'' \times 14''$ or larger: 500 sheets (20 lb) • $8\frac{1}{2}'' \times 11''$ or smaller: 1,000 sheets (20 lb)
3000-sheet finisher (without punch)	<ul style="list-style-type: none"> • Except $8\frac{1}{2}'' \times 11''$: 1,500 sheets (20 lb) • $8\frac{1}{2}'' \times 11''$: 3,000 sheets (20 lb)

- The maximum tray capacity might be less than the above when you use the Rotate Sort, Punch, or Staple function.
- The maximum tray capacity might also be reduced when copy paper is considerably curled.

💡 **Punching (Type 3 only, the optional 3000-sheet finisher and punch kit required)**

You can make punch holes in combination with Sort/Stack/Staple.

💡 **Limitation**

- You cannot make punch holes with Rotate Sort or Rotate Stack.

📌 **Note**

- Originals orientation and punch holes position are as follows:

Original setting		Punch hole position
	Exposure glass	Auto Document Feeder
<input checked="" type="checkbox"/>		
<input checked="" type="checkbox"/>		

🔍 **Reference**


If the punch waste box is full, see ⇒ P.144 “ *Removing Punch Waste*”.

For the size and thickness (paper weight) of paper to which punching is applicable, see ⇒ P.182 “*Punch Kit (Option)*”.


Sort—Sorting Into Sets (123, 123, 123)

Copies can be assembled as sets in sequential order.


❖ Sort



❖ Rotate Sort



❖ Shift Sort



There are three types in the Sort function:

❖ Sort

Copies can be assembled as sets in sequential order.

❖ Rotate Sort

Every other copy set is rotated by 90° and delivered to the copy tray.

❖ Shift Sort (optional finisher required)

Every other copy set is shifted for ease of separation. The shift tray of

the finisher provides this function by sliding from side to side.

⌚ Note

- To switch among Sort, Rotate Sort, and Shift Sort modes, access the user tools. See "6. Sort" in ⇒ P.162 "3. Input/Output 2/2".
- The paper sizes that can be used in Sort function are as follows:

Metric version	A3 <input type="checkbox"/> B4 <input type="checkbox"/> A4 <input type="checkbox"/> B5 <input type="checkbox"/> A5 <input type="checkbox"/>
Inch version	11" × 17" <input type="checkbox"/> , 8 1/2" × 14" <input type="checkbox"/> , 11" × 8 1/2" <input type="checkbox"/> , 5 1/2" × 8 1/2" <input type="checkbox"/>

- The paper sizes that can be used in Rotate Sort function are as follows:

Metric version	A4 <input type="checkbox"/> B5 <input type="checkbox"/>
Inch version	8 1/2" × 11" <input type="checkbox"/>

- To use the Rotate Sort function, two paper trays identical in size and different in direction () are required.

- The paper sizes that can be used in Shift Sort function are as follows:

	1000-sheet finisher	3000-sheet finisher
Metric version	A3 <input type="checkbox"/> , B4 <input type="checkbox"/> , A4 <input type="checkbox"/> , B5 <input type="checkbox"/>	A3 <input type="checkbox"/> , B4 <input type="checkbox"/> , A4 <input type="checkbox"/> , B5 <input type="checkbox"/>
Inch version	11" × 17" <input type="checkbox"/> , 8 1/2" × 14" <input type="checkbox"/> , 8 1/2" × 11" <input type="checkbox"/>	11" × 17" <input type="checkbox"/> , 8 1/2" × 14" <input type="checkbox"/> , 8 1/2" × 11" <input type="checkbox"/>


⌚ Reference

For the paper capacity of the optional finisher, see ⇒ P.49 "Staple".

1 Press the [Sorter] key until the Sort indicator (top) is lit.

2

2 To make punch holes, press the [Punch] key.




• Limitation

- The optional 3000-sheet finisher and punch kit are required to use this function (Type 3 only).
- You cannot make punch holes with Rotate Sort.

• Note

- If you do not make punch holes, go to Step **4**.

3 Make sure that [ON] is selected, then press the [OK] key.



4 Enter the number of copy sets with the [Number] keys.

• Limitation

- The maximum number of sets is 999.

5 Set your originals.

When setting a stack of originals in the document feeder

1 Set a stack of originals in the document feeder, then press the [Start] key.

After all the originals are scanned, the copies are delivered to the tray.

• Note

- The last page should be on the bottom.
- If an original is misfed during sorted copying, reset your originals in the document feeder according to the instruction on the display. The display will indicate the number of originals you should return.

When setting an original on the exposure glass or in the document feeder

• Reference

See ⇒ P.33 "SADF mode"

1 Set the original, then press the [Start] key.

• Note

- Start with the first page to be copied.

2 Set the next original, then press the [Start] key.

 **Note**

- Set the original in the same direction as the first one.

③ After all originals are scanned, press the [#] key.


The copies are delivered to the tray.

2


Stack—Stacking Together All Copies Of A Page (111, 222, 333)

Copies can be assembled with each page set.

❖ **Rotate Stack**



❖ **Shift Stack**



There are two types in the Stack function:

❖ **Rotate Stack**

Every other page set is rotated 90°  and delivered to the copy tray.

❖ **Shift Stack (optional finisher required)**

Every other page set is shifted for ease of separation. The shift tray of the finisher provides this function by sliding from side to side.

 **Note**

- To select Rotate Stack or Shift Stack, access the user tools. See "7. Stack" in \Rightarrow P.162 "3. Input/Output 2/2".
- The sizes that can be used in this function are as follows:

Metric version	A3 <input type="checkbox"/> B4 <input type="checkbox"/> A4 <input type="checkbox"/> <input type="checkbox"/> B5 <input type="checkbox"/> A5 <input type="checkbox"/>
Inch version	11" x 17" <input type="checkbox"/> 8 1/2" x 14" <input type="checkbox"/> 11" x 8 1/2" <input type="checkbox"/> 5 1/2" x 8 1/2" <input type="checkbox"/>

2

The paper sizes that can be used in the Rotate Stack function are as follows:


Metric version	A4 <input type="checkbox"/> <input type="checkbox"/> B5 <input type="checkbox"/> <input type="checkbox"/>
Inch version	8 1/2" x 11" <input type="checkbox"/> <input type="checkbox"/>

To use the Rotate Stack function, two paper trays identical in size and different in direction () are required.


Reference

For the maximum tray capacity of the optional finisher, see ⇒ P.49 "Staple".

1 Press the [Sorter] key until the Stack indicator (bottom) is lit.



2 To make punch holes, press the [Punch] key.




Limitation

- The optional 3000-sheet finisher and punch kit are required to use this function (Type 3 only).
- You cannot make punch holes with Rotate Stack.

Note

- If you do not wish to make punch holes, go to Step 4.

3 Make sure that [ON] is selected. Then, press the [OK] key.



4 Enter the number of copies with the [Number] keys.

5 Set your originals.

When setting a stack of originals in the document feeder

1 Set a stack of originals in the document feeder, then press the [Start] key.

After all the originals are scanned, the copies are delivered to the tray.

Note

- The last page should be on the bottom.

When setting an original on the exposure glass or in the document feeder

 **Reference**

See ⇒ P.33 "SADF mode"

① Set the original, then press the [Start] key.

 **Note**

Start with the first page to be copied.

② Set the next original, then press the [Start] key.

 **Note**

Set the original in the same direction as the first one.

③ After all originals are scanned, press the [#] key.


The copies are delivered to the tray.

Staple

The optional finisher is required to use this function.

Each copy set can be stapled together.

2



 **Limitation**

You cannot use the following paper in this function:

- Post cards
- Translucent paper
- OHP transparencies
- Adhesive labels
- Curled paper
- Low stiffness paper

 **Note**

For this mode, the following limitation apply. When the number of copies exceeds the tray capacity, copying stops. In this case, remove the copies from the shift tray and then resume copying.



❖ Metric version

	1000-sheet finisher	3000-sheet finisher
Paper size	A3□, B4□, A4□□, B5□	A3□, B4□, A4□□, B5□□
Stapler capacity	<ul style="list-style-type: none"> • A4 or smaller: 30 sheets (80 g/m²) • B4 or larger: 20 sheets (80 g/m²) 	<ul style="list-style-type: none"> • A4 or smaller: 50 sheets (80 g/m²) • B4 or larger: 30 sheets (80 g/m²) (without punch)
Shift tray capacity (A4□)	1,000 sheets (80 g/m ²)	3,000 sheets (80 g/m ²)

❖ Inch version

	1000-sheet finisher	3000-sheet finisher
Paper size	11" × 17"□, 8 1/2" × 14"□, 8 1/2" × 11"□□	11" × 17"□, 8 1/2" × 14"□, 8 1/2" × 11"□□
Stapler capacity	<ul style="list-style-type: none"> • 8 1/2" × 11" or smaller: 30 sheets (20 lb) • 8 1/2" × 14" or larger: 20 sheets (20 lb) 	<ul style="list-style-type: none"> • 8 1/2" × 11" or smaller: 50 sheets (20 lb) • 8 1/2" × 14" or larger: 30 sheets (20 lb) (without punch)
Shift tray capacity (8 1/2" × 11"□)	1,000 sheets (20 lb)	3,000 sheets (20 lb)

In the following cases, the copies will be delivered to the shift tray without stapling.

- When the number of copies for one set is over the stapler capacity.
- When memory reaches 0 % during copying.
- When "Add Staple" is displayed during copying.

When you select Staple, Sort mode is automatically selected.

❖ Reference

If you want to add staples, see ⇒ P.134 "Adding Staples".

When staple is jammed, see ⇒ P.139 "Removing Jammed Staples".

 **Stapling position and original setting**

❖ **1000-sheet finisher**

When your machine is equipped with the 1000-sheet finisher, the stapling position will be fixed to 'Top 2'.

Original setting			Stapling position
	Exposure glass	Document Feeder	
Top2	<input checked="" type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

 **Note**

- Original images are not rotated.
- To staple in combination with Combine: 2 pages → 1-sided or 4 pages → 2-sided, or with Double Copies, select paper for originals, or select paper for originals.

❖ **3000-sheet finisher**

When your machine is equipped with the 3000-sheet finisher, stapling positions when there is copy paper that is identical in size and direction as your original are as follows:

Original setting		Stapling position
	Exposure glass	Document Feeder
Top1	<input checked="" type="checkbox"/>	
	<input type="checkbox"/>	
Top2	<input checked="" type="checkbox"/>	
	<input type="checkbox"/>	
Top3	<input checked="" type="checkbox"/>	
	<input type="checkbox"/>	
Double	<input checked="" type="checkbox"/>	
	<input type="checkbox"/>	


Note

- You cannot change stapling positions during copying.
- When the original image is rotated, the stapling direction turns by 90°.
- When you select 1 staple mode (Top or Bottom), the paper of which size is the same but the direction is different from the originals.
- The maximum original image size that can be rotated is as follows:


Metric version	A4
Inch version	8 ¹ / ₂ " × 11"

- The copy image can not be rotated if you select [Top 2] or [Double].
- To staple at the Top 2 or Double position in combination with Combine: 2 pages → 1-sided or 4 pages → 2-sided, or with Double Copies, select paper for originals, or select paper for originals.

1 Press the [Sorter] key until the **Sort** (top) and **Staple** (center) indicators are lit.





2 Select one of four stapling positions.

**Note**


- When your machine is equipped with the 1000-sheet finisher, this display is not available. Go to Step 5.

3 To make punch holes, press the [Punch] key.

**Note**

- If you do not wish to make punch holes, go to Step 4.

4 Press the [OK] key.



5 Enter the number of copy sets with the [Number] keys.

6 Set your originals.

When setting a stack of originals in the document feeder

① Set a stack of originals in the document feeder, then press the [Start] key.

After all the originals are scanned, the copies are delivered to the tray.

 **Note**

The last page should be on the bottom.

When setting an original on the exposure glass or in the document feeder

 **Reference**

See ⇒ P.33 "SADF mode"

① Set the original, then press the [Start] key.

 **Note**

Start with the first page to be copied.

② Set the next original, then press the [Start] key.

 **Note**

Set the original in the same direction as the first one.

③ After all originals are scanned, press the [#] key.

The copies are delivered to the tray.

To stop scanning


When you are using the Sort, Stack, or Staple function, the originals are scanned into memory.

① Press the [Clear/Stop] key.

To resume scanning

① Press the [No] key.

Scanning is resumed.



2


 **Note**

Scanned images in memory are not cleared.

To clear scanned images of the originals

① Press the [Yes] key.

Scanning is stopped with the images cleared.



N02CD0164

When memory reaches 0 %

Scanning will be stopped if the size of scanned image data exceeds memory capacity.

 **Note**

There is enough memory to store approximate 50 originals of A4 size. (Type 1 requires the optional 8 MB copier memory unit.)

- See ⇒ P.187 “Copier Hard Disk (Image Enhance Kit)” for the number of originals that can be stored with the optional copier hard disk.

Reference

Scanning will stop when memory reaches 0% during sorted copying. However, you can change this setting so that all the scanned pages are copied and delivered to the tray first, then the machine automatically continues scanning the remaining originals. See “8. Mem.full-AutoStr” in ⇒ P.162 “3. Input/Output 2/2”.

2

1 Press the [Start] key.

The scanned pages are delivered to the tray. Then, the image data in memory is cleared.

2 Remove the copies and continue copying by following the instructions on the display.

COPYING FROM THE BYPASS TRAY

To use this function on Type 1, the optional bypass tray is required.

Use the bypass tray to copy onto OHP transparencies, adhesive labels, translucent paper, post cards, and copy paper that cannot be set in the paper tray.

● Limitation

- You cannot use the bypass tray for the Duplex function.

◆ Note

- The machine can automatically detect the following sizes as standard size copy papers:

Metric version	A3□, A4□, A5□, 8½" x 13"□
Inch version	A3□, 11" x 17"□, 8½" x 14"□, 8½" x 11"□, 5½" x 8½"□

- If you do not use the standard size copy paper, you should input vertical and horizontal dimensions. The sizes that you can input are as follows:


Metric version	<ul style="list-style-type: none"> • Vertical: 100 – 297 mm • Horizontal: 148 – 432 mm
Inch version	<ul style="list-style-type: none"> • Vertical: 4.0" – 11.7" • Horizontal: 6.0" – 17.0"

○ Reference

For details about paper capacity of the bypass tray, see ⇒ P.23 "Copy Paper".

- 1** If Duplex mode is selected, press the [Duplex] key to cancel the mode.

2 Open the bypass tray.



2


3 Adjust the guides to copy paper size.

● Important

- If the guides are not flush with the copy paper, a skew image or paper misfeeds might occur.

4 Lightly insert the copy paper face down until the beeper sounds.

The  indicator on the display is automatically selected.



ND6100E

1: Horizontal size

2: Vertical size

3: Extender

4: Paper guide



Note


- Do not stack paper over the limit mark; otherwise a skew image or paper misfeeds might occur.
- If the beeper is turned off, lightly insert the copy paper until it stops. See "Settings You Can Change With The User Tools" in the System Settings.
- When the platen cover is open, set the direction of the copy paper to □.
- Swing out the extender to support larger size copy paper larger than A4□, 8 1/2" × 11"□.
- Fan paper to get air between the sheets and avoid a multi-sheet feed.

When copying onto non-standard size copy paper

Important


- You should specify the size of copy paper to avoid paper misfeeds.

① Make sure the indicator is selected.




② Press the [#] key.

③ Press the [Ppr. Size] key.



④ Press the [OK] key.




⑤ Enter the vertical size of the paper with the [Number] keys, then press the [#] key.



Note

- To change the number entered, press the [Clear/Stop] key and enter the new number.

⑥ Enter the horizontal size of the paper with the [Number] keys, then press the [OK] key.




Note

- To change the number entered, press the [Clear/Stop] key and enter the new number.

□ When you specify the paper size, appears on the display to indicate bypass tray copying.


COPYING FROM THE BYPASS TRAY

7 Press the [Exit] key.




When copying onto standard size copy paper

1 Make sure the indicator is selected.




2 Press the [#] key.


3 Press the [Ppr. Size] key.





4 Press the [Next] key until your desired size is displayed.




5 Select the desired size with the and keys, then press the [OK] key.



2



6 Press the [Exit] key.



7 Set your originals, then press the [Start] key.

When copying onto OHP transparencies or thick paper

To make copies onto OHP transparencies or thick paper, you need to specify the paper type.

2

Note

- Select [Thick Paper] if the paper weight is more than 91 g/m² (20 lb).

1 If Duplex mode is selected, press the [Duplex] key to cancel the mode.


2 Open the bypass tray, and adjust the guides to the paper size.

Important

- If the guides are not flush with the copy paper, a skew image or paper misfeeds might occur.

3 Lightly insert the OHP transparencies or thick paper face down until the beeper sounds.

The  indicator on the display is automatically selected.




Note

- When you set a OHP transparencies, make sure that its front and back faces are properly positioned.


□ To avoid paper misfeeds, shuffle a stack of paper before setting it in the tray.

4 Press the [#] key.


5 Press the [Ppr. Type] key.



6 Select [OHP] or [Thick Paper] with the   keys. Then, press the [OK] key.



7 Press the [Exit] key.



Reference

To go on to specify a paper size, press the [Ppr. Size] key.

See ⇒ P.56 "When copying onto non-standard size copy paper".

See ⇒ P.57 "When copying onto standard size copy paper".

8 Set your originals and press the [Start] key.

Important

- When copying onto OHP transparencies, remove copied sheets one by one.

2

PROGRAM—STORING YOUR COPY SETTINGS IN MEMORY

You can store frequently used copy job settings in machine memory, and recall them for future use.

2

❖ Storing Your Settings

You can store your settings you frequently use.

❖ Deleting A Program

You can delete a stored program.

❖ Recalling A Program

You can recall a stored program.


>Note

- You can store up to ten programs.
- Paper settings are stored based on paper size. So if you place more than one paper tray of a same size, the paper tray prioritized with the user tools will be selected first. See “12. Pap.Tray Priority” of the System Settings.
- Programs are not cleared by turning the power off or by pressing the [Clear Modes/Energy Saver] key. They are canceled only when you delete or overwrite them with another program.


Storing Your Settings

1 Edit the copy settings so that all functions you want to store in this program are selected.

2 Press the [Program] key.




3 Press the [Store] key.



4 Select the program number you want to store these settings in with the \leftarrow keys. Then, press the [OK] key.

When the settings are successfully stored, the \Rightarrow indicator appears.




Note

- Program numbers with \Rightarrow already have settings in them.
- If this program number is already being used, the machine will ask you if you wish to overwrite it - press the [Yes] or [No] key.


Deleting A Program

You can delete a stored program.


1 Press the [Program] key.




2 Press the [Delete] key.



3 Select the program number you want to delete with the $\leftarrow\rightarrow$ keys. Then press the [OK] key.



4 Press the [Yes] key.




>Note

To cancel the deletion, press the [No] key.

5 To delete another program, repeat steps **3** and **4**.

6 Press the [Exit] key.



2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317


318

Recalling A Program

You can recall a stored program.


1 Press the [Program] key.

2



2 Select the program number you want to recall with the \leftarrow \rightarrow keys. Then, press the [OK] key.

The stored settings are displayed.



 **Note**

Only programs with \Rightarrow contain a program.

3 Set your originals, then press the [Start] key.

OTHER FUNCTIONS

Energy Saver Mode—Saving Energy

If you do not operate the machine for a certain period after copying, or when you press and hold the [Clear Modes/Energy Saver] key for more than one second, the display disappears and the machine enters Energy Saver mode. When you press the [Clear Modes/Energy Saver] key again, when the originals are set in the document feeder, or when the platen cover or document feeder is opened, the machine returns to the ready condition. In Energy Saver mode, the machine uses less electricity.

The Energy Saver mode makes a two-step reduction in electricity: one for the period up to the time set for Low Power mode, the other for the period after that time.

Note

- The period for which the machine remains in Energy Saver mode (i.e. the period until the mode is turned off to return to the ready condition) varies with the effectiveness of energy saving.
- If you press the [Clear Modes/Energy Saver] key during the operation, the current settings will be cleared.

Reference

See "8. Low Power Timer" of the System Settings.

Interrupt—Temporarily Stopping One Job To Copy Something Else

You can make urgently needed copies during a multi-copy run.

- 1 Press the [Interrupt] key. The key indicator lights.
- 2 Remove the originals currently set for copying, and set your originals for interrupt copying. Make your copies.
- 3 After interrupt copying, remove the originals for interrupt copying and the copies.
- 4 Press the [Interrupt] key again. The key indicator goes off.
- 5 Reset the previous originals. Then, press the [Start] key.

Note

- The previous copy settings are recalled and the previous copy job can be resumed by pressing the [Start] key.

User Codes

If the machine is set to use the User Code function, operators must input their user codes before the machine can be operated. The machine keeps count of the number of copies made under each user code.

Note

- When the machine is set for user codes, the machine will prompt

2

you for your user codes after the operation switch is on or the Auto Reset comes into effect.

□ To prevent others from making copies using your user code, press the **[Clear Modes/Energy Saver]** and **[Clear/Stop]** keys simultaneously after copying.



 **Reference**

For setting user codes, see ⇒ P.154 "1. General Features ^{4/4}".

Auto Start—Entering Copy Job Settings During The Warm-up Period

If you press the **[Start]** key during the warm-up period, the **[Start]** key will blink, and your copies will be made as soon as warm-up finishes.

- 1** Make any adjustments to copy settings during the warm-up period.
- 2** Set your originals.
- 3** Press the **[Start]** key.

The **[Start]** key indicator alternately flashes red and green.

 **Note**

□ To cancel Auto Start, press the **[Clear/Stop]** key.

Original Beeper


The beeper sounds and an error message is displayed when you leave your originals on the exposure glass for about two seconds after copying.

 **Note**

□ To cancel this function, see "06. Original beeper" in ⇒ P.152 "1. General Features ^{2/4}".

PRESET REDUCE/ENLARGE—REDUCING AND ENLARGING USING PRESET RATIOS

You can select a preset ratio for copying.



Note

- You can select one of 12 preset ratios (5 enlargement ratios, 7 reduction ratios).
- You can change the preset ratios to other ratios you frequently use. See “08. Reproduction Ratio” in⇒ P.152 “I. General Features 2/4”.
- You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.
- Copies can be reduced or enlarged as follows:

❖ Metric version

Ratio (%)	Original → Copy paper size
400 (enlarge area by 16)	--
200 (enlarge area by 4)	A5→A3
141 (enlarge area by 2)	A4→A3, A5→A4
122	F→A3, A4→B4
115	B4→A3
93	A little reduced.
87	A3→B4
82	F→A4, B4→F
71 (reduce area by 1/2)	A3→A4, A4→A5
65	A3→F
50 (reduce area by 1/4)	A3→A5, F→A5
35 *1	--
25 *2	--

2

*1 Type 3 only

*2 Type 1 and Type 2 only

❖ Inch version


2

Ratio(%)	Original → Copy paper size
400 (enlarge area by 16)	--
200 (enlarge area by 4)	5 ¹ / ₂ " × 8 ¹ / ₂ " → 11" × 17"
155 (enlarge area by 2)	5 ¹ / ₂ " × 8 ¹ / ₂ " → 8 ¹ / ₂ " × 14"
129	8 ¹ / ₂ " × 11" → 11" × 17"
121	8 ¹ / ₂ " × 14" → 11" × 17"
93	A little reduced.
85	F → 8 ¹ / ₂ " × 11"
78	8 ¹ / ₂ " × 14" → 8 ¹ / ₂ " × 11"
73	11" × 14" → 8 ¹ / ₂ " × 11"
65	11" × 17" → 8 ¹ / ₂ " × 11"
50 (reduce area by 1/4)	11" × 17" → 5 ¹ / ₂ " × 8 ¹ / ₂ "
32 ^{*1}	--
25 ^{*2}	--

^{*1} Type 3 only^{*2} Type 1 and Type 2 only

2 Set your originals, then press the [Start] key.

1 Press the [Enlarge] or [Reduce] key to select a ratio.




Note

- Another preset ratio is displayed every time you press the key.

ZOOM—REDUCING AND ENLARGING IN 1 % STEPS


You can change the reproduction ratio in 1 % steps.



Note

- The following ratios can be selected:
 - Type 1, Type 2
Metric version: 25 – 400 %
Inch version: 25 – 400 %
 - Type 3
Metric version: 35 – 400 %
Inch version: 32 – 400 %
- You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.
- You can select a preset ratio which is near the desired ratio, then press the [Zoom] key and adjust the ratio with the [+] or [-] key.

1 Press the [Zoom] key.




2

2 Enter the ratio.

When using the [+] or [-] key

1 Enter the desired reproduction ratios with the [-] or [+] key.



Note

- To change the ratio in 1 % steps, just press the [+] or [-] key. To change the ratio in 10 % steps, press and hold down the [+] or [-] key.

When using the [Number] keys

1 Enter the desired ratio with the [Number] keys.

 **Note**

- To change the ratio entered, press the **[Clear/Stop]** key and enter the new ratio.

3 Set your originals, then press the **[Start]** key.




DIRECTIONAL SIZE MAGNIFICATION (INCH)—STRETCHING AND SQUEEZING THE IMAGE INTO THE COPY AREA

DIRECTIONAL SIZE MAGNIFICATION (INCH)—STRETCHING AND SQUEEZING THE IMAGE INTO THE COPY AREA

The suitable reproduction ratios will be automatically selected when you enter the horizontal and vertical lengths of the original and copy image you want.

Preparation

Specify the vertical and horizontal sizes of the original and those of the copy, as shown in the illustration.



1: Horizontal original size

2: Vertical original size

3: Horizontal copy size

4: Vertical copy size

Note

□ You can enter sizes within the following ranges:


Metric version	1 – 999 mm (in 1 mm steps)
Inch version	0.1" – 99.9" (in 0.1" steps)

□ If the calculated ratio is over the maximum or under the minimum ratio, it is corrected within the range of the ratio automatically. However, with some ratios, parts


of the image might not be copied or blank margins will appear on copies.

2


1 Press the [Menu] key.



2 Press the [Select] key.



3 Enter the vertical size of the original with the [Number] keys. Then, press the [#] or [>] key.



Note

□ To change the value entered:

- If you have not pressed the [#] key yet, press the [Clear/Stop] key and enter the new value.

- If you have already pressed the [#] key, select the [Orig.:Vrt.] with the   keys and enter the new value.

4 Enter the vertical size of the copy with the [Number] keys. Then, press the [#] or  key.

2

5 Enter the horizontal size of the original with the [Number] keys. Then, press the [#] or  key.


6 Enter the horizontal size of the copy with the [Number] keys. Then, press the [OK] key.

7 Set your originals, then press the [Start] key.

DIRECTIONAL MAGNIFICATION (%)—STRETCHING AND SQUEEZING THE IMAGE IN
1 % STEPS

DIRECTIONAL MAGNIFICATION (%)— STRETCHING AND SQUEEZING THE IMAGE IN 1 % STEPS

Copies can be reduced or enlarged at different reproduction ratios horizontally and vertically.




1: Horizontal %

2: Vertical %

Note


- The following ratios can be selected:
 - Type 1, Type 2
Metric version: 25 – 400 %
Inch version: 25 – 400 %
 - Type 3
Metric version: 35 – 400 %
Inch version: 32 – 400 %
- You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or blank margins will appear on copies.

1 Press the [Menu] key.




2


2 Select the [Direct Mag. (%)] key with \triangle or ∇ keys. Then, press the [Select] key.



3 Enter the desired vertical ratio with the [Number] keys. Then, press the [#] key or the \Rightarrow key.



4 Enter the desired horizontal ratio with the [Number] keys. Then, press the [OK] key.




 **Note**

- To change the number entered, press the [#] key or the  keys, then enter the new number.

5 Set your originals, then press the [Start] key.

MARGIN ADJUSTMENT—ADJUSTING THE MARGIN

You can shift the image either left or right to make a binding margin.



● Limitation

- If you set too wide margin, areas you do not want to delete might be erased.

>Note


- You can change the width of the binding margin as follows:

Metric version	0 – 30 mm (in 1 mm steps)
Inch version	0" – 1.0" (in 0.1" steps)

- The margin width default is as follows. You can change this default setting with the user tools. See "3. Marg.Adjust.Front" in ⇒ P.155 "2. Adjust Image 1/2".


Metric version	<ul style="list-style-type: none"> • Front: 5 mm Left • Back: 5 mm Right
Inch version	<ul style="list-style-type: none"> • Front: 0.2" Left • Back: 0.2" Right

1 Press the [Menu] key.




2

2 Select the [Margin Adjust.] with the $\blacktriangle\triangleright$ keys. Then, press the [Select] key.



3 Select [Left] (left margin) or [Right] (right margin) with the $\blacktriangle\triangleright$ keys.




4 Enter the desired margin width with the [Number] keys.

Note

- To change the value entered, press the [Clear/Stop] key and enter the new value.

5 To specify a binding margin for back pages, press the [Back] key.




2



Note

- You can specify the back margin only when the Duplex or the Two-Sided copy with Combine is selected.
- If you do not need to specify the back margin, press the [OK] key and go to Step **6**.

6 Select [Left] (left margin) or [Right] (right margin) with the <*> keys.




7 Enter the desired margin width the [Number] keys. Then, press the [OK] key.

8 Set your originals, then press the [Start] key.

ERASE CENTER/BORDER—ERASING THE CENTER AND THE BORDER


This function erases the center and/or all four sides of the original image, such as book originals.

❖ Erase Center



CenterEE

❖ Erase Border



BorderEE

There are two types in this function:

❖ Center

This mode erases the center margin of the original image.

❖ Border

This mode erases the surrounding area of the original image.

>Note


You can change the width of the erased margin as follows:

Metric version	3 – 50 mm (in 1 mm steps)
Inch version	0.1" – 2.0" (in 0.1" steps)

The default setting of the erased margin is as follows. You can change this settings with the user tools. See "1. Erase Border" and "2. Erase Center" in ⇒ P.155 "2. Adjust Image 1/2".

Metric version	10 mm
Inch version	0.4"


The position of the margin to be erased is determined according to the original size and reproduction ratio.



1: Erased part

You can use the Erase Center and Erase Border functions together.


1 Press the [Menu] key.



2

2 Select the [Erase Ctr./Bdr.] with the   keys. Then, press the [Select] key.


2




3 Select the part to be erased.

Center

① Press the [Center] key.




② Enter the center width with the [Number] keys. Then press the [OK] key.



 Note


□ To change the value entered, press the [Clear/Stop] key and enter the new value.

③ Press the [Exit] key.




Border

① Press the [Border] key.



② Enter the border width with the [Number] keys. Then press the [OK] key.




 Note

□ To change the value entered, press the [Clear/Stop] key and enter the new value.

ERASE CENTER/BORDER—ERASING THE CENTER AND THE BORDER

③ Press the [Exit] key.



④ Set your originals, then press the [Start] key.


COMBINE—COMBINING ORIGINALS INTO ONE COPY

The optional document feeder is required to use this function.


2

You can make 1 sheet of copies from 2 or more one-sided originals.


❖ 2 pages→1-sided



❖ 16 pages→booklet



❖ 4 pages→1-sided, 4 pages→2-sided



1: Front

2: Back

There are five types in this function.

❖ 2 pages→1-sided

This mode makes two facing pages on one-sided copy.

❖ 4 pages→1-sided

4 one-sided pages are copied on to 1 one-sided sheet.


❖ 4 pages→2-sided (Type 1 requires the optional 8 MB copier memory unit and duplex unit.)

4 one-sided paper are copied onto 1 two-sided sheet, 2 original images on each side.

❖ 8 pages→2-sided (Type 1 requires the optional 8 MB copier memory unit and duplex unit.)

8 one-sided pages are copied on to 1 two-sided sheet, 4 original images on each side.

❖ 8 pages→2-sided




COMBINE—COMBINING ORIGINALS INTO ONE COPY

❖ **16 pages→booklet (Type 1 requires the optional 8 MB copier memory unit and duplex unit.)**


This mode makes a booklet copy of 16 pages from 16 one-sided originals.

Setting Originals (Originals set in the document feeder)

- Originals reading from left to right



- Originals reading from top to bottom



● **Limitation**

- You cannot use this function in Duplex mode.
- You cannot use the bypass tray with this function.
- The machine cannot copy originals different in size and direction.

● **Note**

- The number of originals copied (combined) can be 2, 4, 8, or 16.
- In this mode, the machine selects the reproduction ratio automatically. This reproduction ratio depends on the copy paper sizes and the number of originals.

- The machine uses ratios in the following range:

- Type 1, Type 2
Metric version: 25 – 400 %
Inch version: 25 – 400 %
- Type 3
Metric version: 35 – 400 %
Inch version: 32 – 400 %


- If the calculated ratio is under the minimum ratio, it is corrected within the range of the ratio automatically. However, with some ratios, parts of the image might not be copied or blank margins appear on copies.

- Separation line between originals can be printed with the user tools. See "6. Combine Copy" in ⇒ P.157 "2. Adjust Image 1/2".

- Even if the direction of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.

- You can make copies even if the number of originals is less than the number required in the selected mode. You can also disable this function with the user tools. See "2. Comb. Auto Eject" in ⇒ P.160 "3. Input/Output 1/2".

- When the number of originals placed is less than the number specified for combining, the last page (s) will be copied blank as shown in the illustration.




2

□ In the 4 pages→2-sided mode or 8 pages→2-sided mode, you can specify the orientation of originals ([Top to Top]/[Top to Bottom]). See ⇒ P.88 "Specifying Orientation of Bound Originals".




1 If Duplex mode is selected, press the [Duplex] key to cancel the mode.


2 Press the [Menu] key.




3 Press the [↓Next] key until the [Combine] is displayed.



4 Press the [Select] key.



5 Select the desired combine modes with the $\leftarrow\rightarrow$ keys. Then, press the [OK] key.



6 Press the [Exit] key.

7 Press the [Paper] key or $\leftarrow\rightarrow$ keys to select the copy paper.

8 Set your originals, then press the [Start] key.

When setting an original on the exposure glass or in the document feeder

1 Set the original, then press the [Start] key.

Note

□ Start with the first page to be copied.

2 Set the next original, then press the [Start] key.

Note

□ To finish copying, press the [#] key to eject the copy.

When setting a stack of originals in the document feeder

1 Set your originals, then press the [Start] key.


Note

□ The last page should be on the bottom.

COMBINE—COMBINING ORIGINALS INTO ONE COPY

 **Making a booklet**

If you want to make a booklet from 16 originals, fold copies as shown in the illustration.



2

SERIES COPIES—MAKING ONE-SIDED COPIES FROM VARIOUS ORIGINALS

2

You can make one-sided copies from two facing pages of bound (book) originals and from two-sided originals.

There are two types in this function:

❖ **Book → 1-Sided**

You can make one-sided copies from two facing pages of a bound (book).


❖ **2-Sided → 1-Sided (The optional document feeder is required.)**

You can make one-sided copies from two-sided originals.

● **Limitation**

You cannot use this function in Duplex mode.

Book → 1-Sided—Making One-sided Copies From Two Facing Page Of A Bound Original (Book)



✍ **Note**

Refer to the following table when you select original and copy paper sizes with 100 % ratio:

❖ **Metric version**


Original	Copy paper
A3	A4 <input type="checkbox"/> × 2 sheets
B4	B5 <input type="checkbox"/> × 2 sheets
A4	A5 <input type="checkbox"/> × 2 sheets

❖ **Inch version**

Original	Copy paper
11" × 17" <input type="checkbox"/>	8 1/2" × 11" <input type="checkbox"/> × 2 sheets
8 1/2" × 11" <input type="checkbox"/>	5 1/2" × 8 1/2" <input type="checkbox"/> × 2 sheets


1 If Duplex mode is selected, press the [Duplex] key to cancel the mode.

2 Press the [Menu] key.




SERIES COPIES—MAKING ONE-SIDED COPIES FROM VARIOUS ORIGINALS

3 Press the [**↓Next**] key until [Series] is displayed.




4 Select [Series] with the **◀▶** keys. Then, press the [Select] key.



Without the optional document feeder

1 Press the [OK] key.




2

5 Set your originals, then press the [Start] key.


With the optional document feeder

1 Select the [Book → 1-Sided] with the **◀▶** keys. Then, press the [OK] key.




2-Sided→1-Sided—Making One-sided Copies From Two-sided Originals


The optional document feeder is required to use this function.




- 1 If Duplex mode is selected, press the [Duplex] key to cancel the mode.
- 2 Press the [Menu] key.



- 3 Press the [↓Next] key until [Series] is displayed.
- 4 Select [Series] with the $\triangle\blacktriangleright$ keys. Then, press the [Select] key.




- 5 Press the [OK] key.



- 6 Set your originals, then press the [Start] key.

- 3 Press the [↓Next] key until [Series] is displayed.



DUPLEX—MAKING TWO-SIDED COPIES

Type 1 requires the optional duplex unit, interchange unit, and 8 MB copier memory unit is required to use this function.

There are three ways in this function:

❖ **1-sided → 2-sided**

This mode makes two-sided copies from one-sided originals.

❖ **Book → 2-sided**

This mode makes two-sided copies from facing pages of a bound original (book).

❖ **2-sided → 2-sided**

This mode makes two-sided copies from two-sided originals.

● **Limitation**

□ You cannot use the following copy paper in this function:

- Paper smaller than A5, 5¹/₂" × 8¹/₂"
- Translucent paper
- Adhesive labels
- OHP transparencies
- Post cards

□ You cannot use the bypass tray with this function.


□ The optional copier hard disk is required to make enhanced-image copies.

● **Note**

□ The following paper limitations apply:

Inch version	Minimum size	5 ¹ / ₂ " × 8 ¹ / ₂ "
	Weight	20 – 28 lb

□ When you make 2-sided copies on B4, 8¹/₂" × 14" or larger copy paper, open the right side cover. Also open the bypass tray, if installed.




2

Metric version	Minimum size	A5
	Weight	64 – 105 g/m ²

1-Sided → 2-Sided—Making Two-sided Copies From One-sided Originals

2




Note

- If you set an odd number of 1-sided originals in the document feeder (ADF), the reverse side of the last page is left blank. You can disable this function to make the delivered last page not be blank. See "1. Duplex Auto Eject" in ⇒ P.160 "3. Input/Output 1/2".
- When original images are copied, the images are shifted by a width of binding margin. You can adjust the binding margin or binding position. You can also change their default values. See "4. Margin Adjust Back" in ⇒ P.155 "2. Adjust Image 1/2".

Originals and copy direction


You can select the orientation ([Top to Top], [Top to Bottom]). See ⇒ P.88 "Specifying Orientation of Bound Originals".

- Top to Top




Duplex1

- Top to Bottom



Duplex2

DUPLEX—MAKING TWO-SIDED COPIES




Original direction and completed copies

The resulting copy image will differ according to the direction in which you set your original (lengthwise □ or widthwise □)

Original	Orientation	Result ^①
 Duplex3	 Duplex5	<ul style="list-style-type: none"> • [Top to Top]  Duplex9
	 Duplex6	<ul style="list-style-type: none"> • [Top to Bottom]  Duplex10
 Duplex4	 Duplex7	<ul style="list-style-type: none"> • [Top to Top]  Duplex11
	 Duplex8	<ul style="list-style-type: none"> • [Top to Bottom]  Duplex12

^① The illustrations show the directions of copied images on the front and back, not the directions of delivery.

1 Press the [Duplex] key until the 1-Sided→2-Sided indicator (top) is lit.



2

2 Set your originals.

When setting an original on the exposure glass or in the document feeder

Reference

See ⇒ P.33 "SADF mode"

1 Set the original, then press the [Start] key.

Note

Start with the first page to be copied.

2 Set the next original, then press the [Start] key.

When setting a stack of originals in the document feeder

1 Set your originals, then press the [Start] key.

Note


The last page should be on the bottom.

Specifying Orientation of Bound Originals


You can specify the orientation of bound originals (how you turn the pages). The default setting is [Top to Top].

2


1 Press the [Menu] key.




2 Press the [**↓Next**] key until [Orientation] is displayed.




3 Select the [Orientation] with the **◀▶** keys. Then press the [Select] key.



4 Select the desired orientation with the **◀▶** keys. Then, press the [OK] key.



Book → 2-Sided—Making Two-Sided Copies From Facing Pages Of A Bound Original (Book)



>Note

- Refer to the following table when you select original and copy paper sizes with 100 % ratio:


❖ Metric version

Original	Copy paper
A3	A4 (2-sided)
B4	B5 (2-sided)
A4	A5 (2-sided)

❖ Inch version

Original	Copy paper
11" × 17"	8 1/2" × 11" (2-sided)
8 1/2" × 11"	5 1/2" × 8 1/2" (2-sided)

1 Press the [Duplex] key until the Book→2-Sided indicator (center) is lit.



2

2 Set your originals.

When setting an original on the exposure glass or in the document feeder

1 Set the original, then press the [Start] key.

>Note

- Start with the first page to be copied.

2 Set the next original, then press the [Start] key.

When setting a stack of originals in the document feeder


1 Set your originals, then press the [Start] key.

Note


- The last page should be on the bottom.

2-Sided → 2-Sided—Making Two-sided Copies From Two-sided Originals

2



1 Press the [Duplex] key until the 2-Sided→2-Sided indicator (bottom) is lit.



2 Set your originals.

When setting an original on the exposure glass or in the document feeder

1 Set the original, then press the [Start] key.

 **Note**

Start with the first page to be copied.

2 Set the next original, then press the [Start] key.

When setting a stack of originals in the document feeder

1 Set your originals, then press the [Start] key.

 **Note**

The last page should be on the bottom.

COVER/PAPER DESIGNATE—ADDING OR INSERTING SHEETS

In this function, you can add or insert cover or paper designate.

There are three types in this function:

❖ **Front Cover (Type 1 requires the optional bypass tray)**

The first page of your originals is copied on a specific paper sheets for covers.

❖ **Both Covers (Type 1 requires the optional bypass tray)**

The first and last pages of your originals are copied on specific paper sheets for covers.

❖ **Paper Designate**

Any specified page of your originals is copied on specific paper sheets for slip sheet.

 **Note**

- The cover or slip sheets should be identical in size and direction with the copy paper.
- If Blank Cover mode is selected, the cover will not be counted as a copy.


Front Cover—Copying Or Adding A Front Cover

2


Type 1 requires the optional bypass tray to use this function.

The first page of your originals is copied on a specific paper sheets for covers.

❖ **Copy**




❖ **Blank**



 **Note**

- The optional 8 MB copier memory unit is required to make 2 or more sets of copies on Type 1.
- You can specify whether to make a copy on a sheet for covers. If you select [Copy], the first page will be copied on the cover sheet. If you select [Blank], a cover sheet will just be inserted before the first copy.

1 Press the [Menu] key.




2


2 Press the [\downarrow Next] key until [Cover/ Ppr.Des.] is displayed.




3 Press the [Select] key.




4 Press the [Front] key.



5 Specify whether to copy on a cover sheet with the \leftarrow \rightarrow keys. Then, press the [OK] key.



6 Press the [Exit] key.



7 Set cover sheets on the bypass tray.


8 Set your originals, then press the [Start] key.

Both Covers—Copying Or Adding Front And Back Covers


Type 1 requires the optional bypass tray to use this function.

The first and last pages of your originals are copied on specific paper sheets for covers.

❖ Copy




❖ Blank



>Note


- You can specify whether to make a copy on a cover sheet. If you select [Copy], the first and last pages will be copied on the cover sheets. If you select [Blank], a cover sheet will just be inserted before the first copy and another sheet after the last copy.

1 Press the [Menu] key.




2


2 Press the [\downarrow Next] key until [Cover/ Ppr. Des.] is displayed.




3 Press the [Select] key.



4 Press the [Both] key.




5 Specify whether to copy on a cover sheet with the   keys. Then, press the [OK] key.



2

6 Press the [Exit] key.




7 Set cover sheets on the bypass tray.

8 Set your originals, then press the [Start] key.

Paper Designate—Copying Designated Pages Of Originals Onto Slip Sheets


Any specified page of your originals is copied on specific paper sheets for slip sheet.



Note

- You can specify up to 10 page numbers.
- Before using this function, set the special paper tray for slip sheets using the user tools. See "09. Slip Sheet Tray" in ⇒ P.153 "1. General Features 3/4".

1 Press the [Menu] key.



COVER/PAPER DESIGNATE—ADDING OR INSERTING SHEETS

2 Press the [**↓Next**] key until [Cover/Ppr. Des.] is displayed.

Function Menu > 1/4		Select with
D. Size Mag. (Inch)	Direct. Mag. (%)	Margin Adjust. Erase Ctr./Bdr.
Margin Adjust.	Erase Ctr./Bdr.	
↑Prev.	↓Next	Exit
Select		



3 Press the [Select] key.

Function Menu > 3/4		Select with
Cover/Ppr. Des.	OHP Slip Sheet	Sp. Paper-Bypass
↑Prev.	↓Next	
Exit	Select	



4 Press the [Ppr. Des.] key.

Cover/Paper Designate >		Select mode(s)
Front	Both	Ppr. Des.
Exit		



Note

- If your machine is not equipped with the bypass tray, the display above does not appear. Go to Step **5**.

5 Enter the page number you want to copy onto a slip sheet with the [Number] keys. Then, press the [#] key.

Ppr. Des. >		Enter page, press @		
1:__Pg	2:__Pg	3:__Pg	4:__Pg	5:__Pg
6:__Pg	7:__Pg	8:__Pg	9:__Pg	10:__Pg
Cancel				
OK				

Note

- To change the value entered, press the [**Clear/Stop**] key and enter the new value.

6 To specify another page number, repeat Step **5**.

7 When you finish specifying the page number (s), press the [**OK**] key.

Ppr. Des. >		Enter page, Press @		
1:5Pg	2:10Pg	3:15Pg	4:__Pg	5:__Pg
6:__Pg	7:__Pg	8:__Pg	9:__Pg	10:__Pg
Cancel				
OK				




Note

- To change the number entered, select the desired item with the keys, then enter the new number.

8 Press the [Exit] key.

Cover/Paper Designate >		Select mode(s)
Paper Designate X 3		
Front	Both	Ppr. Des.
Exit		



9 Set your originals, then press the [**Start**] key.

2


OHP SLIP SHEET—COPYING OR INSERTING SLIP SHEET

Type 1 requires the optional bypass tray.


2

Whenever a different original is copied in OHP Slip Sheet mode, a slip sheet will be placed after each copy, or a slip sheet will be fed and the same original image is copied onto this slip sheet.

❖ **Copy**



❖ **Blank**



● **Limitation**


□ You cannot use this function in Duplex mode.

✍ **Note**


- Set slip sheets of the same size and in the same orientation as OHP transparencies.
- You can specify whether to make copies onto the inserted slip sheets.
- If you do not copy onto a slip sheet, the sheet is excluded from the number of copies counted.

1 If Duplex mode is selected, press the [Duplex] key to cancel the mode.


2 Press the [Menu] key.



3 Press the [↓Next] key until [OHP Slip Sheet] is displayed.




4 Select the [OHP Slip Sheet] with the keys. Then, press the [Select] key.



OHP SLIP SHEET—COPYING OR INSERTING SLIP SHEET

5 Specify whether to copy on a slip sheet with the $\triangle\blacktriangleright$ keys. Then, press the [OK] key.



6 Set OHP transparencies in the bypass tray.


7 Set the slip sheets in the paper tray, then select this tray pressing the [Paper] key or the $\triangle\blacktriangleright$ keys.

8 Set your originals, then press the [Start] key.


POSITIVE/NEGATIVE—COPYING IN COMPLEMENTALY COLORS

If you use a black and white original, black and white areas of the original are reversed.


2




1 Press the [Menu] key.



2 Press the [\downarrow Next] key until [Positive/Negative] is displayed.



3 Press the [Select] key.



4 Set your originals, then press the [Start] key.

IMAGE REPEAT—REPEATING AN IMAGE

You can copy the original image repeatedly, or make two copies of the same image on one sheet.

There are two types in this function:

❖ Double Copies


The one original image is copied twice on one copy.

❖ Image Repeat

The original image is copied repeatedly.

Double Copies—Copying The Image Twice On One Page

The one original image is copied twice on one copy as shown in the illustration.



! Limitation

The following originals cannot be detected properly on the exposure glass. Be sure to select the copy paper manually or set the originals in the optional document feeder.

Metric version	A5□, B6□
Inch version	5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ "□

You cannot use the bypass tray for the Double Copies function.

>Note

Two copy images appear vertically on □ paper for □ originals, and horizontally on □ paper for □ originals.

You can insert separate lines between repeated images. See "5. Double Copy" in ⇒ P.157 "2. Adjust Image $\frac{1}{2}$ ".

Refer to the following table when you select original and copy paper sizes with 100 % ratio:

❖ Metric version

Original size and direction	Copy paper size and direction
A5□	A4□
B6□	B5□
A4□	A3□
A5□	A4□
B6□	B5□


❖ Inch version

Original size and direction	Copy paper size and direction
5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ "□	8 $\frac{1}{2}$ " x 11"□
5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ "□	8 $\frac{1}{2}$ " x 11"□
8 $\frac{1}{2}$ " x 11"□	11" x 17"□


2

1 Press the [Menu] key.


2




2 Press the [↓Next] key until [Image Repeat] is displayed.



3 Select [Image Repeat] with the <> keys. Then, press the [Select] key.




4 Press the [OK] key.



5 Set your originals, then press the [Start] key.

Image Repeat—Repeating An Image Over The Entire Copy

The original image is copied repeatedly.



Note


□ The number of repeated images depends on the original size, copy paper size, and reproduction ratio. Refer to the following table.

◆ Original: $5\frac{1}{2}'' \times 8\frac{1}{2}''$ □ /Copy
paper: $8\frac{1}{2}'' \times 11''$ □ or Original: $5\frac{1}{2}'' \times 8\frac{1}{2}''$ □ /Copy paper $8\frac{1}{2}'' \times 11''$ □

4 repeats (71 %)	16 repeats (35 %)


IMAGE REPEAT—REPEATING AN IMAGE

❖ Original: $5\frac{1}{2}'' \times 8\frac{1}{2}''$ □/Copy
paper: $8\frac{1}{2}'' \times 11''$ □ or Original: $5\frac{1}{2}'' \times 8\frac{1}{2}''$ □/Copy paper $8\frac{1}{2}'' \times 11''$ □




- Part of a repeated image might not be copied depending on copy paper size, copy paper direction or reproduction ratio.
- You can insert separate lines between repeated images. See "7. Image Repeat" in⇒ P.157 "2. Adjust Image $2\frac{1}{2}''$ ".


- 1 Select the size of the copy paper and the reproduction ratio.
- 2 Press the [Menu] key.




3 Press the [\downarrow Next] key until [Image Repeat] is displayed.



4 Select [Image Repeat] with the $\leftarrow\rightarrow$ keys. Then, press the [Select] key.



5 Select [Image Repeat] with the $\leftarrow\rightarrow$ keys. Then, press the [OK] key.



6 Set your original, then press the [Start] key.

ARCHIVE FILE—STORING THE IMAGES OF YOUR ORIGINALS INTO MEMORY

The optional copier hard disk is required to use this function.



You can store images you frequently use, and recall and copy them any time.

There are four types in this function:

❖ Storing The Images

Stores image pages you frequently use.

❖ Deleting The Stored Images

Deletes a set of image pages already stored.

❖ Printing A List Of The Stored Images

Makes a combined copy of each first page of all the stored files (8 pages into one 1-sided, or 16 pages into one 2-sided).

❖ Recalling The Stored Images

Recalls a set of stored image pages and copies them onto the A4, 8 $\frac{1}{2}$ " x 11" copy paper.

❖ Note


- The maximum capacity is 16 files or 32 pages. If you store more than two pages in one file, the maximum number of files might be less than 16.
- Image pages to be stored should be A4, 8 $\frac{1}{2}$ " x 11" size.
- The functions that can be stored are as follows:
 - 1-sided copy or 2-sided copy
 - Type of originals
 - Image density
- Set your originals on the exposure glass.

The stored images are not cleared by turning the power off or by pressing the [Clear Modes/Energy Saver] key. They are canceled only when you delete or overwrite them.


Storing The Images

You can store images you frequently use.


1 Press the [Menu] key.




2 Press the [↓Next] key until [Archive File] is displayed.



3 Select [Archive File] with the <> keys. Then, press the [Select] key.




4 Press the [Store] key.



2

5 Select the file number you want to store the images in with the <> keys. Then, press the [OK] key.



Note

- File numbers with already have images in them.

To overwrite images already stored

1 Check the stored content, and select whether to overwrite it.

Note

- You can check the stored content by printing a list of the stored images. See ⇒ P.106 "Printing A List Of The Stored Images".

2 Press the [Yes] key to overwrite the images, or press the [No] key not to overwrite them.


Are you sure you want to delete the stored file?

Yes No


Note

- When you overwrite with another images, the previously stored images will be lost.

6 Select the type of originals with the   keys. Then, press the [OK] key.

2

8 Press the [OK] key.



ND2C0104

Note


- If you are using Type 1 without the duplex unit installed, the display above does not appear. Go to Step **7**.

7 Set your originals on the exposure glass, then press the [Start] key.

The images will be scanned.

Note

- If you have more than one original pages, repeat the steps above.
- Start with the first page of your originals.



CP158E

1: Reference position


Deleting The Stored Images

You can delete images already stored.


Note

Images are deleted on a file basis.


1 Press the [Menu] key.




2 Press the [↓Next] key until [Archive File] is displayed.



3 Select [Archive File] with the keys. Then, press the [Select] key.




4 Press the [Delete] key.




2

5 Select the file number you want to delete the images in with the keys. Then, press the [OK] key.



6 Press the [Yes] key.



Yes


No



Note

To cancel deletion, press the [No] key.

7 Press the [Exit] key.



Printing A List Of The Stored Images


You can make a combined copy of each first page of all the stored files (8 pages into one 1-sided, or 16 pages into one 2-sided).

2


Note

- If any file number has nothing stored, its page will be copied in blank with no image or number.


1 Press the [Menu] key.




2 Press the [↓Next] key until [Archive File] is displayed.




3 Select [Archive File] with the $\leftarrow\rightarrow$ keys. Then, press the [Select] key.



4 Press the [List] key.



5 Select the [8pages→1sided] or [16pages→2sided] with the $\leftarrow\rightarrow$ keys.



Note

- [16pages→2sided] is not available, if your machine is Type 1 without the duplex unit.

6 Press the [Start] key.


Recalling The Stored Images

You can recall stored images to copy them onto A4, 8 $\frac{1}{2}$ " × 11" paper.


Note

Copies are made on a file basis.


1 Press the [Menu] key.




2 Press the [↓Next] key until the [Archive File] is displayed.



3 Select the [Archive File] with the keys. Then, press the [Select] key.



4 Select the desired file number with the keys.



2

Note

Only files with  contain images.

5 Enter the number of copies with the [Number] keys.

Note

The maximum number of copies is 99.

6 Press the [Start] key.

COMBINATION CHART

The combination chart given below shows which modes can be used together. When you read the chart, please refer to the following table.



☆	means that these modes can be used together.
→	means that these modes cannot be used together. The mode after you select will be the mode you're working in.
×	means that these modes cannot be used together. The mode before you select will be the mode you're working in.

The following shows the combinations of functions.

		Mode after you Select															
		Mode before you select															
		Mode before you select															
		>Selecting Copy Paper	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Auto Paper Select	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Auto Reduce/Enlarge	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Enhanced Image Copy	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Sort	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Rotate Surt/Route Stack	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Shift Surt/Shift Stack	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Staple	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Presst Reduct/Enlarge	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Zoom	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Directional Size Magnification (inch)	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Directional Magnification (%)	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Margin Adjustment	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Erase Centre/Border	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		2 pages → 1-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Combine	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		4 pages → 1-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		4 pages → 2-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		8 pages → 2-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		16 pages → booklet	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Series Copies	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		2-sided → 1-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		OHP Slip Sheet	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Portrait/Negative	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Book → 2-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		2-sided → 2-sided	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Cover/Drill/Origate	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Image Repeat	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
		Image Repeat	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆

COMBINATION CHART

2

^{*1} Available if the optional copier hard disk is installed.

*2 When you select the mode after you select, the machine returns to Auto Reduce/Enlarge mode. However, you can select the mode before you select again.

³ The Paper Designate function is available. The optional copier hard disk is required to use the Cover function.

2